


JVC

SERVICE MANUAL

CD CHANGER CONTROL TUNER DECK

KS-CG10 B/E/G/GE/GI



DIGIFINE

- This manual is a revised edition of G version (No. 49142)
- The SK/DK circuit is only for the G version.
- The DYNAS system has been modified from the intermediate system. Although the FM P.C. board and parts lists are presented, any FM adjustment method is not described. Until the FM adjustment method is published, therefore, the FM P.C. board should be replaced by the P.C. board ass'y.

FEATURES

- Detachable Control Panel
- CD changer control
- Random Play/Repeat Play
- Disc Scan (KS-CG10 B/E/GI)
- High Sensitivity Tuner
- DYNAS* (Dynamic Selectivity & Sensitivity) Tuner
- AM/FM-Stereo PLL Synthesizer Tuner
- 24-Station Preset Tuning (FM-18, AM(MW/LW)-6)
- Scan/Seek/Manual Tuning
- Strong-station Sequential Memory (SSM)
- SK/DK Traffic Information Reception (KS-CG10 G/GE)
- U-Turn Auto-Reverse Logic Mechanism
- SA (Sen-Alloy) head
- Multi Music Scan**/Blank Skip/ Repeat
- Intro Scan (KS-CG10 B/E/GI)
- Dolby***B/C Noise Reduction
- Auto Tape Select Mechanism
- Loudness Button
- AUX Terminal (Front Panel)
- Subwoofer control
- Illumination Color Button
- Clock Button
- Line Input/Output Terminals
- Wireless remote control

* DYNAS is a trademark of H.u.C. Elektronik GmbH.

** "Under Licence of Staar S.A., Brussels, Belgium".
 *** Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

Contents

	Page		Page
1	Instruction Book (Extract)	2	
2	Location of Main Parts	14	
3	Removal of Main Parts	15	
4	Main Adjustment	18	
5	Block Diagram	21	
6	Standard Schematic Diagram	22	
7	Wiring Connections	28	
8	Location of P.C. Board Parts and Parts List	29	
9	Exploded View of Mechanism Component Parts and Parts List	44	
10	Exploded View of Enclosure Component Parts and Parts List	47	
11	Packing Illustration and Parts List	49	

1 Instruction Book (Extract)

SPECIFICATIONS

RADIO SECTION

Frequency Range

FM: 87.5 – 108.0 MHz

AM: (MW) 522 – 1,620 kHz

(LW) 144 – 281 kHz (Manual)

144 – 279 kHz (Auto)

[FM Tuner]

Usable Sensitivity: 8.2 dBf (0.7 μ V/75 Ω)

50 dB Quieting Sensitivity: 16.3 dBf

(1.8 μ V/75 Ω)

Alternate Channel Selectivity: (100 kHz) 35 dB

Frequency Response: 40 – 15,000 Hz

Stereo Separation: 30 dB

Capture Ratio: 1.5 dB

[MW Tuner]

Sensitivity: 20 μ V

Selectivity: 35 dB

[LW Tuner]

Sensitivity: 50 μ V

CASSETTE DECK /AUDIO AMPLIFIER SECTION

Wow & Flutter: 0.09 % (WRMS)

Fast Wind Time: 100 sec. (C-60)

Frequency Response (NR-OFF):

40 – 20,000 Hz (± 3 dB) (Metal/CrO₂ tape)

40 – 18,000 Hz (± 3 dB) (Normal tape)

Signal-to-Noise Ratio (Normal tape)

(Dolby C NR on): 68 dB

(Dolby B NR on): 60 dB

(Dolby NR off): 52 dB

Stereo Separation: 40 dB

Tone control Range

Bass: ± 10 dB at 100 Hz

Treble: ± 10 dB at 10 kHz

Line-Input Level/Impedance:

0.5 V/20 k Ω

Line-Output Level/Impedance:

0.5 V/20 k Ω load (250 nWb/m)

GENERAL

Power Requirement

Operating Voltage: DC 14.4 V (11 V - 16 V Allowable)

Grounding System: Negative Ground

Dimensions (W x H x D)

Installation Size: 178 x 50 x 140 mm

Panel Size: 169 x 46 x 25 mm

Gross Weight: 2.1 kg (4.7 lbs)

Design and specifications subject to change without notice.

ELECTRICAL CONNECTIONS

To prevent short circuits, while making connections, keep the battery's negative terminal disconnected.


We recommend that you make all electrical connections before installing the unit. If you're not sure how to correctly install this unit, have it installed by a qualified service technician.

Note:

This unit is designed for 12 volt DC, Negative Ground. If your vehicle does not have a 12 volt negative ground electrical system you need a voltage inverter which can be bought from a JVC "IN-CAR ENTERTAINMENT" dealer.

- Be sure to ground this unit to the car's chassis.



A. Connections



■ Layout drawing showing place of adjustments

● AM PCB

● FM PCB



● SK/DK PCB





Fig. 4-2

5 Block Diagram

■ Block Diagram of Signal (G version type)




Fig. 5-1

6 Standard Schematic Diagram

■ Tuner Circuit 1/2




Fig. 6-1


B. Line terminal connections

Since this unit has line-input/output terminals, a CD player, amplifier and other equipment can be used to upgrade your car stereo system.


- When connecting a JVC CD player, connect this unit's line/CD-in terminals and also connect both CD remote leads. Sound from the CD player is automatically selected having priority over other sources with these connections.

- When connecting an amplifier, connect this unit's line-out terminal to the amplifier's line-in terminals.
- When a unit without a remote wire is connected to the line-in terminals of the KS-CG10, set to the AUX mode using the FUNC button.
- When the KS-CG10 is connected to a JVC Digital Acoustics Processor KS-DP100, set the VOLUME control of KS-CG10 to maximum.

1. 2-amplifier connection





2. Single amplifier connection (Front or Rear)



C. AUX terminal connection

A commercially available portable CD player, etc., can be connected to the AUX terminal in the front panel. Set to the AUX mode using the FUNC button.



Cautions:

- When playing a car CD player, etc. connected to Line/CD in terminals and a portable CD player, etc. connected to the AUX terminal at the same time, sound from both sources will be heard simultaneously.
- Disconnect the portable CD player when listening to the radio since noise may occur.
- Do not leave the portable CD player in the car when you leave the car.

D. Subwoofer out terminal connections


Since this unit has subwoofer out terminals, an amplifier and subwoofer can be used to upgrade your car stereo system.

- When using a subwoofer, the BASS control of the KS-CG10 should be set to its center position.

E. Power aerial (Automatic antenna) connections


This set is equipped for the automatic extension and retraction of a power aerial when the power switch is turned on and off. The connection from the audio unit (REMOTE blue with white line lead) is via a separate relay to the fully automatic aerial motor unit incorporating a built-in terminal circuit.

LOCATION OF CONTROLS



(KS-CG10 B/E/GI)

(When the control panel is opened)



(KS-CG10 G/GE)

F. Memory back-up lead


Connect this lead to a position where live power is supplied even when the ignition key is taken out.

G. Fader control


- When used in a 4-speaker system**
Use this control to balance the volume levels of the front and rear speakers. Set to the fader mode using the SELC button and press the ► side of the level control button to decrease the volume levels of the rear speakers and press the ◀ side to decrease those of the front speakers. The overall volume level can be adjusted in the volume mode. (See page 22.)
- When used in a 2-speaker system**
Set this control to the center position.

- Control panel
- POWER/Attenuator (ATT) switch
POWER: Press to turn the power on.
Depress for more than 1 second to turn the power off.
ATT: When this button is pressed while the unit is operating, the volume drops and the level indicator blinks. Press again to return to the original volume.
- Preset station buttons (No. 1-No. 6)
Music scan preset buttons (No. 1-No. 6)
Disc number buttons (No. 1-No. 6)
- Remote sensor section
- Microcomputer reset button
- AUX jack
- Level control buttons
Use to adjust the volume, bass, treble, fader and balance. (See page 22.)
- Function (FUNC) button
Used to select the source.
- Electronic control mode select (SELC) button
- Loudness (LOUD) button
Subwoofer (SUB WF) button
- CLOCK button
- Display window
- Illumination color (ILL) button
- Random (RNDM) button
Dolby B/C (B/C) button
DYNAS button
- Repeat (RPT) button
Scan (SCAN) button
SSM button
- Disc scan (D. SCAN) button
Local (LO) button
Intro (INT) button
- Disc select (-) button
Blank Skip (B. SKIP) button
Manual (M)/SEEK button
- Disc select (+) button
Program (PROG) button
BAND button
- Control panel open (OPEN) button
Eject (▲) button
- Tuning/Time adjustment/Fast wind/Skip (search) button
Down frequency/Hour adjustment (▼)/Rewind (◀◀)
UP frequency/Minute adjustment (▲)/Fast forward (▶▶)
- SK/DK button (KS-CG10 G/GE)
- Cassette loading slot

23



24




23 Indicators (for audio control section)

Volume (VOL)
 BASS (bASS)
 Treble (TRE)
 Fader (FAd)
 Balance (bAL)
 Subwoofer (SUB)
 Loudness (LOUD)
 Level indicator

24 Indicators (for tuner section)

Band (F1-F2-F3-A)
 Preset Station
 Radio frequency
 SEEK
 SK/DK (KS-CG10 G/GE)
 Local (LO) (KS-CG10 B/E/GI)
 FM Stereo (ST)
DYNAS

25



26



25 Indicators (for tape deck section)

Tape direction (◀▶)
 Dolby B (B) NR
 Dolby C (C) NR
 Blank skip (B. SKIP)
 Repeat (↺)
 Music scan preset (MS)

26 Indicators (for CD changer control/other sections)

Repeat (↺)
 Disc number
 Track number
 DISC
 TRACK
 RDM 1
 RDM 2

 EEEE
 HHHH
 Time

REMOTE CONTROL UNIT

- Installing batteries in the remote control unit.


Using the remote control unit

To use the remote control unit, point it at the remote sensor and press the buttons gently and firmly.

Do not expose the remote sensor to strong light (direct sunlight or artificial lighting) and make sure that there are no obstacles between the remote sensor and the remote control unit.


The following operations can be performed using the remote control unit.


- Check the functions of the operation buttons carefully and operate them correctly.



- 1 Function (F) button
Used to select the source.
- 2 Illumination color (ILL) button
- 3 DISC select (DISC) button
- 4 Seek tuning/Fast wind/Skip (Search) button
Down seek (↺)/Rewind (◀◀)
- 5 VOLUME level control buttons (–/+)
- 6 Attenuator (A) button
- 7 BAND/Program (PROG)/DISC select (+) button
- 8 Seek tuning/Fast wind/Skip (Search) button
Up seek (↗)/Fast forward (▶▶)

Audio level control



Electronic control mode		
BASS Bass	BASS  Decreases	BASS  Boosts
TRE Treble	TRE  Decreases	TRE  Boosts
FAD Fader	FAD  Rear	FAD  Front
BAL Balance	BAL  Left	BAL  Right
VOL Volume	VOL  Decreases	VOL  Increases

- When the power is turned on, the unit is set to the volume mode. The modes are changed by pressing the SELC button. When more than 5 seconds have elapsed after the level is adjusted in any mode, it will return to the volume mode automatically.
- Even when the power is turned off, the current settings are stored in memory.
- * As for the previous level control, only the volume control can be adjusted by remote control.

LOUDNESS BUTTON

At low volumes, the human ear is less sensitive to high and low frequencies. When the volume is low, press the LOUD button for more than 1 second to boost the sound at high and low frequencies to output well-balanced sound.

SUBWOOFER BUTTON


To control the signal level output to the subwoofer out terminal when a subwoofer is connected. Each time the SUB WF button is pressed, the output level changes from low level to high level, off, then back to low level.

ILLUMINATION COLOR BUTTON

To match the color of this unit's display with that of the instrument panel, you can choose between two colors – amber and green.

To detach the control panel

- ① Press the OPEN button to open the control panel.
- ② Pull the control panel out of the main unit as shown in the figure below.
 - After detaching the control panel, put it in the case provided for protection.
- ③ After removing the control panel, reset the control panel holder to its original position.





To attach the control panel

- ① Insert the top of the control panel under the lip at the top of the holder.
- ② Press the lower side of the control panel to fix it.


Notes:

1. Press the OPEN button momentarily; the control panel opens and the cassette will be ejected. If the OPEN button is pressed for more than 1 second, only the control panel opens and the cassette will not be ejected.
2. Set the power switch of the KS-CG10 to off before detaching the control panel. If the ignition is switched off, the control panel cannot be detached.
3. Be careful not to damage the connector terminals when attaching/detaching the control panel or while the control panel is detached.


①



②



Incorrect

**TAPE OPERATION**

Operate in the order shown.

① POWER/ATT Switch on.	② Press the OPEN button.*	③ Insert cassette.	④ See below.	⑤ Select program.
⑥ SELECT BASS/TRE/FAD/BAL/VOL Adjust.				

* Cassette can be inserted and ejected even when the power is set to off.

DOLBY NR BUTTON

Each time the B/C button is pressed, the Dolby NR System will be changed from Dolby B NR to Dolby C NR to Dolby NR off, in that order.

IGNITION KEY-OFF RELEASE (KEY-ON PLAY) MECHANISM


When the ignition key is turned off, this "key-off release" mechanism will automatically release the tape from the magnetic head. This will set the mechanism to the standby mode. When the key is turned on, it will automatically return to the playback mode.

AUTO TAPE SELECT MECHANISM

This unit has an Auto Tape Select mechanism which distinguishes between different types of tape. When the type of tape has been detected, equalization is set to suit for the tape.

- Cassettes with detection holes:
 - Metal tape (EQ: 70 μ s)
 - CrO₂ (chrome) tape (EQ: 70 μ s)
- Cassettes without detection holes:
 - Normal tape (EQ: 120 μ s)

Some earlier types of metal and CrO₂ (chrome) tapes may not be provided with detection holes. Avoid using such tapes, since correct equalization characteristics cannot be obtained. Also do not use ferrichrome tapes whose characteristics do not match this unit.



TO FAST FORWARD AND REWIND THE TAPE

Press the ►► button to fast forward the side being played back; when the end of the tape is detected, the tape is reversed and played back from the beginning of the other side. Press the ◄◄ button to rewind the tape. When the tape is rewound to the beginning, it is played back again. Press the PROG button to start play from the current position during the fast forward or rewind mode.


AUTO-REVERSE MECHANISM

When the tape reaches the end of one side, this mechanism automatically switches over to play back the other side. To listen to the other side while playing one side, press the PROG button. The change in the tape transport direction can be checked from the Tape Direction indicators.

MULTI MUSIC SCAN OPERATION

This function enables you to play back automatically from the beginning of the required tune by skipping over a maximum of 6 tunes in the forward or reverse direction.

- Example (to skip over 6 tunes)



- ① Load the cassette and press Music Scan Preset button (number 6).
- ② Press the ◄◄ or ►► button.
 - When the beginning of the required tune is detected, the indication number of the selected tune goes out and the tape starts playback.

Note:

During scanning, when the tape is rewound to the beginning in the rewind mode, it is played back from the beginning of this side, when the tape reaches the end in the fast-forward mode, it is reversed and played back from the beginning of the other side.

INTRO SCAN (KS-CG10 B/E/GI)

Use Intro Scan to quickly locate the required tune.

- When the INT button is pressed during playback, the unit enters the fast-forward scan mode and each time a tune is located, the beginning of each tune is played back for approx. 15 seconds. Press the INT button when the required tune is located. Intro Scan operates continuously for both sides of the tape.

Note:

When Intro Scan is performed from the beginning of the tape or in the middle of a tune, the first tune will be skipped and the Intro Scan operation starts from the next tune.

BLANK SKIP

During playback, when there is a blank section of more than 15 seconds between tunes with this button set to on, the tape is fast forwarded to the beginning of the next tune. This operation is also used with auto reverse to skip to the first tune on the other side after the end of the last tune on one side.

REPEAT FUNCTION

Push the RPT button while a tune you would like to hear over again is being played back. When the tape reaches the end of the tune, the tape is automatically rewound to the beginning of that tune and playback resumes from there. This operation will be repeated till the RPT button is pushed again.



Note:

In the following cases, the Multi Music Scan, Intro Scan, Blank Skip and Repeat function mechanisms may not operate correctly. This is not a malfunction; use the mechanisms to accommodate the program material and situation.

- Tapes with tunes having long pianissimo passages (very quiet parts) or non-recorded portions during tunes.
- Tapes with tunes recorded at low recording levels.
- Tapes with short non-recorded sections.
- Tapes with high level noise or hum between tunes.
- The Dolby B/C NR button settings do not match the tape's NR mode.

RADIO OPERATION

Operate in the order shown.



MANUAL TUNING

Set to the manual mode using the M/SEEK button. When SEEK is not shown in the display, the unit is in the manual mode. Then, by pressing the Tuning button, you can move up and down the frequency band. The frequency band is scanned as long as either side of this button is pressed. You can step through the frequency in 50 kHz units for FM, 9 kHz units for MW and 1 kHz unit for LW.

In AM operation, the frequency moves continuously from the MW (522 – 1,620 kHz) to the LW (144 – 281 kHz) band and vice versa.


- Manual tuning cannot be performed using remote control.

SEEK TUNING

Set the seek mode using the M/SEEK button; the SEEK indicator will light. Then, by pressing the $\wedge$ or $\vee$ button the unit tunes to the adjacent station with a higher or lower frequency.

In AM operation, the frequency moves continuously from the MW to the LW band and vice versa.

- Seek tuning can be performed using remote control.




SCAN BUTTON TUNING

Use the SCAN button for automatic scanning of the FM and AM (MW/LW) frequency bands. When this button is pressed, each station is monitored for approx. 5 seconds, and the frequency flashes during this time. After 5 seconds have elapsed, the frequency is advanced to the next station which in turn is monitored for 5 seconds. To stop scanning, press the SCAN button again.

PRESET BUTTON TUNING

6 stations in each band (F1, F2, F3 and A(MW/LW)) can be preset as follows;

- **Example (when presetting Preset Station button "6" to FM station at 103.5 MHz)**



- ① Select the F1 band using the BAND button.
 - ② Set to the manual mode.
 - ③ Tune to the desired station.
 - ④ Press Preset Station button "6" for more than 2 sec. (When "6" flashes in the Preset Station display, the station is preset.)
- Repeat the above procedure for each of the other 5 stations using a different Preset Station button each time.
 - Follow the above procedure for the other bands (F2, F3 and A(MW/LW)).

Notes:

- The previous preset station is erased when a station is newly preset because the new station is stored in memory.
- The preset station is erased when the power supply to the memory circuit is interrupted during battery replacement, etc. When this occurs, preset the station again.

STRONG-STATION SEQUENTIAL MEMORY (SSM)

This function searches for FM and AM (MW/LW) stations broadcasting strong signals; the 6 strongest stations are held in memory in the order of increasing frequency and can be recalled with preset buttons 1 – 6.

(Procedure)

- ① Press the SSM button for more than 3 seconds.
- ② The 6 strongest signals in the band to which you are listening (F1, F2, F3 and A (MW/LW)) will be searched and selected automatically. These 6 stations are preset in preset buttons (1 – 6) in the order of increasing frequency. (During this operation "----" lights in the display.)
The receiver then tunes to the broadcast stored in preset button "1" automatically.

Note:

Previously preset stations are cancelled automatically when SSM is used.

MONO BUTTON

When listening to FM, set the MO button to stereo or mono.

Note:

Set to mono when a stereo FM broadcast is too noisy and cannot be heard satisfactorily.

LOCAL BUTTON (KS-CG10 B/E/GI)

Set the LO button as desired.

- Set to off during normal use.
- Set to on when only strong signal stations are required in scan tuning and seek tuning.

FM PULSE NOISE SUPPRESSOR

This unit has built-in circuitry to effectively eliminate engine noise picked up by the antenna, etc. in the form of FM pulses, for more favorable FM reception.

CD AUTOMATIC CHANGER OPERATION




PRECAUTIONS

- This unit is for the control of the JVC Compact Disc Automatic Changer (to be purchased separately).
- For use, refer to the instructions of the CD automatic changer.
- When a cassette tape is loaded while listening to a CD, CD playback is automatically switched to cassette playback.
- When there is no disc in the disc magazine of the CD automatic changer or when the disc is inserted into the tray upside down, the "---" blinks in the KS-CG10 display. In such a case, remove the disc magazine from the CD changer and set the discs correctly.
- The CD Automatic Changer stops automatically when the ambient temperature rises above a certain level; "HHHH" will be shown in the display of the KS-CG10. If this happens, leave the CD changer for a while, until the temperature drops before using it again. During this time, you can listen to the tuner, etc. by switching the source using the Function (FUNC) button of the KS-CG10.
- When "EEEE" is shown in the display of the KS-CG10, confirm that the cord is connected and press the RESET button of the CD changer.

PLAYING COMPACT DISCS

To play all tunes

Operate in the order shown.




- After the last tune of the first disc has been played, the disc on the next tray automatically starts from its beginning. If there is no disc on the tray, the display shows the "---" then the following disc is played.

DISC SELECTION

• Direct Disc Selection

Press the disc No. button (1 – 6) corresponding to the No. of the required disc. CD play starts when the disc No. and track No. indicator light.


Example : (to designate Disc 5)



• Disc select button

Press the disc select button (+/-) to select the required disc.

- DISC +



Example: (when the Disc 3 is currently playing...)


- Each time the (+) side is pressed, the 4th, 5th, 6th and 1st disc ... will be selected in sequence.
- Each time the (-) side is pressed, the 2nd, 1st and 6th disc ... will be selected in sequence (when this unit is connected to the XL-MK1200, disc selection is performed from the 1st disc to 12th disc to 11th disc ...).

SKIP PLAYBACK

- During playback, when skipping to the beginning of the next tune or the tune being played back or the previous tune, the beginning of the tune is easily located and the playback starts from there.


To listen to the next tune ...

Press the ►► button once to skip to the beginning of the next tune.



To listen to the previous tune ...


Press the ◀◀ button to skip to the beginning of the tune being played back and press again to skip to the previous tune.



- * When the disc select and skip operations are performed in sequence, the required tune from the required disc can be selected.

SEARCH PLAYBACK (to locate the required position on the disc)

- The required position can be located using fast-forward or reverse search during playback.
- Hold down the button and the search playback starts slowly and then gradually increases speed.
- Since a small sound (about one quarter of playback level) is audible in both modes, release the button when the required position is located while monitoring the sound.



REPEAT PLAYBACK

When the RPT button is pressed, the tune being played is repeated. Press this button again to cancel repeat playback. The ↺ indication goes out and all-tune playback is resumed.

If this unit is connected to the JVC CD changer XL-MG600, it is possible to repeat a single tune or all tunes of the current disc. (The ↺ indication blinks during all-tune repeat operation.)

DISC SCAN (D. SCAN) (KS-CG10 B/E/GI)

When the D. SCAN button is pressed, the first 10 seconds of the first tune on every disc in the magazine are played back sequentially. When the required disc is located, press this button again and normal playback will start.

RANDOM PLAYBACK

Each time the RNDM button is pressed, the mode is changed from the RDM1 mode to the RDM2 mode to the clear mode, in this order.

RDM1: Plays all tunes on the disc currently being played back once, in random order then subsequent discs, in order.


RDM2: Randomly select a CD other than the disc being played and a tune is selected at random and played.

DIGITAL CLOCK DISPLAY

To check the time, press the CLOCK button and the time will be displayed. When the radio or a CD is operated in the time mode, the display will switch to frequency or disc number and track number and then, after a short time, it will return to the time mode. To cancel the time mode, press the CLOCK button again.

- **To adjust the time**

When the display is in the time mode, while keeping the CLOCK button pressed, press the Hour adjustment button () to adjust the "hours" and press the Minute adjustment button () to adjust the "minutes."



2 Location of Main Parts

■ Deck Unit




Fig. 2-1

■ Controller Unit



Controller Unit Parts No.

KS-P10E Controller unit E/B/GI
KS-P10G Controller unit G/GE

Controller Unit

Fig. 2-2

3 Removal of Main Parts

< Outer Components >

■ Controller and controller holder (Fig. 3-1 ~ 3-3)

1. Remove the two set screws ① in the upper cover.
2. Insert a screwdriver between the upper cover and the chassis to remove it from section B.
3. Depress solenoid ① and lower the controller holder forward as indicated at ② in the figure.
4. Remove the screw ② that secures the controller and remove it by pulling it in the direction indicated by the arrow at ③ in the figure.
5. Remove the two set screws ③ in the controller holder, pull it out and disconnect the CN913, CP703, CN703 and CP702 connectors which connect it to the main PCB.




Fig. 3-1

■ Cassette Mechanism Assembly (Fig. 3-4)

1. Remove the upper cover.
2. Disconnect connectors CP801 and CP852. (Mechanism control PCB)
These connectors are easily removed by inserting a straight-bladed screwdriver between the connector and the plug.
3. Remove the four set screws ⑤ ⑥ in the mechanism assembly.
4. Remove the head wire connector (CP802). (Raise the mechanism assembly slightly to remove it.)




Fig. 3-2

■ Dolby NR PCB Assembly (Fig. 3-5)

1. Remove the upper cover.
2. Remove the set screw ⑦ in the Dolby PCB holder.
3. Pull out the PCB. (Disconnect the cord connector at this time.)
4. Disconnect the graphics equalizer and changer input cord connector if required.




Fig. 3-3

■ FM/AM PCB Assembly (Fig. 3-5 and 3-1)

1. Remove the top cover.
2. Remove the set screw (8) in the PCB holder.
3. Raise the AM PCB to remove it.
4. Remove the set screw (9) in the FM tuner pack shield plate.
5. If required, remove the set screw (10) in the rear bracket to remove the antenna cord.




Fig. 3-4

■ Line Output Cord

1. Remove the top cover.
2. Remove the mechanism assembly.
3. Remove the DOLBY NR PCB.
4. Disconnect line output cords CP971 and CP531 from the main PCB.
(The use of a straight-bladed screwdriver facilitates this operation.)

■ CD Line/Remote Input

1. Remove the top cover.
2. Remove the DOLBY NR PCB.
3. Remove the bush of the CD cord/remote cord and disconnect CP931 from the main PCB.




Fig. 3-5

■ Main PCB Assembly (Fig. 3-4 and 3-1)

1. Remove the top cover.
2. Remove the controller holder.
3. Remove the FM/AM PCB assembly.
4. Remove the four screws (6 and 4) to remove the mechanism assembly.
5. Remove the two set screws (11) in the rear bracket.
6. Remove the two set screws at the top of the main PCB.
7. Remove the main PCB with the rear bracket attached.

< Mechanism Components >

■ Playback Head (52)

1. Remove the two screws (58).
2. Remove the (90) screw from the head PCB.
3. Pull out the entire head mount base (20).
4. Remove the two screws (53) in the front part of the head.
5. Disconnect the head PCB wires.




Fig. 3-6




Fig. 3-7

■ Capstan Motor (68)

1. Remove the two screws (72) at the bottom of the chassis.
2. Remove the belt from the pulley. (The belt (80) is on the motor side.)
3. Disconnect motor wiring.
4. Pull out the pulley (69).




Fig. 3-8




Fig. 3-9

■ A. Motor (47)

1. Remove the three screws (87) and the E-ring (88) and lower the L/E slider.
2. Remove the screw (86).
3. Remove the A gear unit and assembly together.
4. Remove the two screws (51) and take out the A gear (1) (50) and the A motor bush (49).
5. Disconnect the wiring.

- When the components are installed, set the head in FWD direction, the direction plate (56) and actuator plate (11) in the direction of the drive PCB direction.




Fig. 3-10

■ Flywheel bracket (82)

1. Remove the screw (83).
2. Press the bracket in towards the AUTO PCB to remove it.

Now the belt (80) and flywheel assembly (78) can be replaced.




Fig. 3-12




Fig. 3-11

4 Main Adjustment

■ Measuring devices and jigs required in the adjustments

- | | | | |
|---------------------------|-------------|----------------|---|
| ● Electronic voltmeter | ● Test Tape | | |
| ● Oscilloscope | VTT704 | 12.5 kHz | : Azimuth adjustment |
| ● Frequency counter | VTT712 | 3000 Hz 0 dB | : Wow and flutter/tape speed measurements |
| ● Wow and flutter meter | VTT724 | 1 kHz -4 dB | : Standard level adjustment |
| ● Low frequency generator | TMT732 | 125/1 k/8 k Hz | : Check of frequency characteristics |
| ● Torque meter | TMT735 | 1 k/12.5 kHz | : Check of frequency characteristics |
| ● FM signal generator | VTT722 | 1 kHz 0 dB | : Standard level |
| ● AM signal generator | TMT6447 | | : Check of music scan operation |
| | TMT6448 | | : Check of music scan operation |

■ Measuring Conditions


- | | | | |
|-----------------------|--|-----------------------------------|--|
| ● Power voltage | 14.4 DCV (reduced voltage 10.5 V) | ● Standard input | |
| ● Load | 10 k Ω line output connected | (SSG direct reading) | AM: 74 dB, FM: 66 dB |
| ● Standard setting .. | FADER, BASS and TREBLE at center position and DOLBY NR set to OFF. | ● Standard control position | The position where playback of the VTT724 produces a 300 mV line output. |

■ Synchronization Signal Generator (SSG)

- AM: 400 Hz, 30% modulation
- FM: 400 Hz, 22.5 kHz deviation
- FM STEREO: 1 kHz 67.5 kHz deviation; pilot signal 7.5 kHz
- Output level: 0 dB = 1 μ V, 50 Ω open pin?

■ Dummy Load

Both the AM and FM bands use a special dummy. However, when the FM dummy is used, a 6 dB loss occurs between the SSG output and antenna input.



● Presetting (Original Setting)

Preset No.	1	2	3	4	5	6
Band						
FM	87.5 MHz	89.9 MHz	97.9 MHz	105.9 MHz	108.0 MHz	87.5 MHz
AM	144 kHz	153 kHz	522 kHz	603 kHz	1404 kHz	1620 kHz

● Manual Selection

- FM: 50 kHz
- AM: UP/DOWN control in 9 kHz steps.

Note: The dB indications used in this manual Fm which is a direct reading of the SSG output is the inspection standard plus 6 dB.

■ Adjustments to be done before installing mechanical components

Items	Check Points	Place of Adjustments	Conditions	Adjustment Procedures
Clock adjustment	TP704	TC701	No input Connect the clock pin of the TP705 to ground to short-circuit it.	1. Connect the clock pin of the TP705 to ground to short-circuit it. 2. Adjust the TC701 so that an F. counter connected to TP704 indicates 1048570 ~ 1048582 Hz.



■ Cassette Section Adjustments

Items	Place of Adjustments	Tape Used	Conditions	Adjustment Procedures
Head azimuth adjustment	Head adjusting screws Forward adjusting screw  Reverse adjusting screw 	VTT704	Maximum output The difference between FWD/REV levels must be less than 3 dB.	1. Adjust the output level to maximum, tighten the screw when the phase difference is 0° and adjust it to approximately 90°. (The output should be less than 3 dB from peak level.) 2. Use a syringe to lock screws, springs and the head base after the adjustment (# 1401C).
Tape speed and wow/flutter adjustments	_____	VTT712	Speed: 2940 ~ 3090 Hz Wow•Flutter: 0.35% — JIS RMS	1. Wind VTT712 to the beginning and start playback. 2. Connect a frequency counter and a wow/flutter meter to the playback output pin to check whether it meets the prescribed standard.
DOLBY NR level adjustment	VR301: Lch VR401: Rch	VTT724	The output level of test point TP501 should be -8.5 dBs ± 1 dB	1. Adjust the VR301 and VR401 so that the output level of the TP501 on the DOLBY PCB is -8.5 dBs ± 1 dB. The difference between FWD/REV levels must be less than 3 dB.
Check of playback frequency characteristics	VR302: Lch VR402: Rch	TMT735 (1 k, 12.5 k) TMT732 (125, 1 k, 8 k)	Use test point TP501 to make the following adjustments: 1 kHz/12.5 kHz: 0 ± 0.5 dB 1 kHz/125 Hz: 0 ± 0.5 dB	1. Play back the TMT735 test tape and adjust the VR302 and VR402 so that the 12.5 kHz level difference for 1 kHz is less than ± 0.5. 2. Play back the TMT732 test tape and adjust the VR302 and VR402 so that the 125 kHz level difference for 1 kHz is less than 0 ± 3 dB.
Check of line output	_____	_____	IN: 1 kHz 300 mV OUT: 210 ~ 420 mV	Check that the LINE OUT outputs a voltage of 210 mV ~ 420 mV when a 1 kHz 300 mV signal is input to the AUX and the control is set to maximum.
Check of subwoofer output	_____	_____	IN: 80 Hz 100 mV OUT: 280 mV	Make sure that the signal from the subwoofer output is 280 mV or more when an 80 Hz, 100 mV signal is input to the AUX/CD input and the subwoofer is set to maximum volume.

■ Receiver Section

	Items	Check Points	Place of Adjustments	Conditions	Adjustment Procedures
FM Section In case the FVM is in trouble, refer to the Quality Assurance Department of Personal Audio Division. #1 ~ #1000 FM Ass'y No. VDG3311-003CF (G version). #1001 ~ FM Ass'y No. VDG3311-093CF (B/E/G version).					
6	AM VT adjustment		L55 TC51	AM 530 kHz AM 1710 kHz	1. Set TC51 to its mechanical center position to center its capacity value. (approximately 90°C) 2. Adjust L55 so that the output at the VT pin is 1.2 V at 530 kHz. 3. Adjust TC51 so that the output at VT pin is 8.5 V at 1710 Hz. 4. Perform procedures 2 and 3 repeatedly and end with procedure 2.
7	Tracking adjustment	AF output		Minimum output level which allows adjustment	1. Adjust L53, L54 L56 and L57 so that the output reaches maximum at a reception of 600 kHz. 2. Adjust TC51 so that the output reaches maximum at a reception of 1500 kHz.

■ Major performance standards for mechanical elements

Item	Conditions	Standard	Remarks
Power supply	Standard power supply	Voltage: 13.2 DCV $\pm$ 20%	
Power consumption	Tape used: C60 Applied voltage: 13.2 DCV	Playback (at the end of the reel): Less than 150 mA	
		Fast forward (at the end of the reel): Less than 200 mA (Reel lock): Less than 300 mA	
Head position	Special gauge	Recording/Playback: 3.1 ~ 3.8 mm	
		Music scan: 4.4 ~ 5 mm	
Tape drive power	Cassette type torque gauge: CTG-N	Playback: More than 90 g-cm	The pinch roller should return to original position when pressure is released.
	Tension gauge	Pinch roller Pressure: 350 ~ 500 g	
Take up torque	Cassette type torque gauges: TW2111A (FWD PLAY) TW2121A (REV PLAY) CTG-N (FF•REW)	Playback: 30 ~ 75 g-cm	
		Fast forward: 80 ~ 160 g-cm	
		Rewind: 80 ~ 160 g-cm	
Fast-wind time	Tape used: C60	Fast forward: Less than 120 sec	
		Rewind: Less than 120 sec	

How to distinguish the new and old versions of KS-CG10

OLD PARTS NO.	PARTS NAME	NEW PARTS NO.
VDG3311-003CF	FM Board Ass'y	VDG3311-093CF
ZCKSCG10G-NPA	Controller Unit	KS-P10G
VJG1007-016	NOSE Piece Ass'y	ZCKSCG10GR2-NPA
VNN3311-211	NOSE Piece	VJC1007-014
	Instructions	VNN3311-212

KS-CG10 G Version

In case the new board ass'y VDG3311-093CF is attached to the existing FM board ass'y VDG3311-003CF in KS-CG10, the existing ass'y can be used as a substitute by performing the following modification:

1. Modification of SK/DK Board Ass'y

Since the SK/DK detector level is too low in the case of the new board ass'y (VDG3311-093CF) board ass'y, it is necessary to modify this ass'y to increase the level as follows:


- (1) Addition of 1 μ F/50 V E. capacitor (C522)
- (2) One Pattern should be cut off.
- (3) After removing one chip part (0 Ω), two wires should be added on both sides of the part.

2. Adjustment of AUTO. stop sensitivity

Since the AUTO. stop sensitivity level is by 2 ~ 4 dB lower in the case of the new DYNAS board ass'y, it is necessary to modify this ass'y to increase the sensitivity level as follows:


- (1) Connect SSG to the Ant. terminal to add a 20 ~ 22 dB μ level, and adjust the level with VR701 so that the voltage at the TP704 SD terminal becomes 5 V. The VR rotation angle is 5° ~ 10° in counterclockwise direction.

Modification of SK/DK # 1 ~ # 1000




Results # 1001 ~

Addition of C522



Main board parts side




How to distinguish the new and old versions of KS-CG10 is presented below

Old version: Product # 1 ~ # 1000

New version: Product # 1001


Old Version (# 1 ~ # 1000)

■ Surface of the Set (Controller Unit)




Whether the DYNAS switch is provided or not.


New Version (# 1001 ~)




■ Top Side View




The quantity of parts is different.




■ FM Board (Parts Side)




The IC size is different.




This P.C. board is provided above the IC.



■ SK/DK Board



Whether C522 is provided or not.



■ Tuner Circuit 2/2 (G/GE Version)






Fig. 6-2


■ Amplifier Circuit 1/2 (G/GE Version)



■ Amplifier Circuit 2/2 (G/GE Version)



■ DOLBY NR Circuit (G/GE Version)



■ Tuner Circuit 2/2 (B/E/GI Version)





Fig. 6-6

■ Amplifier Circuit 1/2 (B/E/GI Version)



■ Amplifier Circuit 2/2 (B/E/GI Version)




Fig. 6-8

■ Indicator/Switch Circuit (B/E/GI Version)




Fig. 6-9

(No. 49142) 26D

■ Indicator/Switch Circuit (G/GE Version)





Fig. 6-10

7 Wiring Connections



8 Location of P.C. Board Parts and Parts List

The FM board is compatible with the unit. Meanwhile, the P.C. board diagram and parts list are not presented here.
(FM P.C. Board Ass'y No. VDG3311-003CF) (# 1 ~ # 1000 for G/GE version) or VDG3311-093F (other than the above version) (# 1001 ~ for G/GE version)




Fig. 8-1




Fig. 8-2

● FM Board Parts List

FWI BOARD Parts List						BLOCK NO. 04		BLOCK NO. 04	
A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX				
C	802	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V					
C	803	QEK41CM-226	E CAPACITOR	.22MF 20% 16V					
C	804	QEK41HM-224	E CAPACITOR	.022MF 10% 50V					
C	805	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V					
C	811	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V					
C	812	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V					
C	813	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	814	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	815	QEE40JM-106B	E CAPACITOR	10MF 20% 6.3V					
C	816	NC121CH-121AY	C CAPACITOR	120PF +50:-10%					
C	817	NC121CH-121AY	C CAPACITOR	120PF +50:-10%					
C	818	NC121CH-560AY	C CAPACITOR	56PF +50:-10% 1					
C	819	NC121CH-560AY	C CAPACITOR	56PF +50:-10% 1					
C	820	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V					
C	821	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V					
C	822	NEF11VM-104LY	TS E CAPACITOR	.10MF 20% 35V					
C	823	NCB21HK-153AY	C CAPACITOR	.015MF 10% 50V					
C	824	NCB21HK-332AY	C CAPACITOR	3300PF 10% 50V					
C	825	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	826	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	827	NC121CH-122AY	C CAPACITOR	1200PF +50:-10%					
C	828	NC121CH-121AY	C CAPACITOR	120PF +50:-10%					
C	829	NC121CH-122AY	C CAPACITOR	1200PF +50:-10%					
C	833	NCB21HK-272AY	C CAPACITOR	2700PF 10% 50V					
C	831	NCB21HK-272AY	C CAPACITOR	2700PF 10% 50V					
C	832	QEF80JM-225X	E CAPACITOR	2.2MF 20% 6.3V					
C	833	QEF80JM-225X	E CAPACITOR	2.2MF 20% 6.3V					
C	834	NCB21HK-472AY	C CAPACITOR	4700PF 10% 50V					
C	835	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	836	NC121UJ-560AY	C CAPACITOR	56PF 5%					
C	837	NC121UJ-331AY	C CAPACITOR	330PF 5%					
C	838	QEK41CM-106	E CAPACITOR	10MF 20% 16V					
C	839	NCB21EK-683AY	C CAPACITOR	.068MF 10% 25V					
C	840	NEF11VM-224LY	TS E CAPACITOR	.22MF 20% 35V					
C	841	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	842	NCB21EK-333AY	C CAPACITOR	.033MF 10% 25V					
C	843	NEF11VM-224LY	TS E CAPACITOR	.22MF 20% 35V					
C	844	QEK41CM-476	E CAPACITOR	.47MF 20% 16V					
C	845	QEF80JM-225X	E CAPACITOR	2.2MF 20% 6.3V					
C	846	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	847	NC321HK-102AY	C CAPACITOR	1000PF 10% 50V					
C	848	QEF81CM-474X	TS E CAPACITOR	.47MF 20% 16V					
C	849	NC321HJ-181AY	C CAPACITOR	180PF 5% 50V					
C	850	NCB21HK-152AY	C CAPACITOR	1500PF 10% 50V					
C	851	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V					
C	852	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	855	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	856	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V					
C	857	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V					
C	858	NCB21HK-102AY	C CAPACITOR	1000PF 10% 50V					
C	859	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V					
C	861	NCB21EK-333AY	C CAPACITOR	.033MF 10% 25V					
C	871	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V					
C	872	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V					
C	873	QER41CM-476M	E CAPACITOR	47MF 20% 16V					

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C	874	QEK41EM-475	E CAPACITOR	4.7MF 20% 25V	
C	875	NCB21HK-152AY	C CAPACITOR	1500PF 10% 50V	
C	877	NEF11AM-105LY	TS E CAPACITOR	1.0MF 20% 10V	
C	878	NCB21HK-472AY	C CAPACITOR	4700PF 10% 50V	
C	879	QEK41EM-475	E CAPACITOR	4.7MF 20% 25V	
C	880	QEK41HM-224	E CAPACITOR	.22MF 20% 50V	
C	881	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V	
C	882	NCB21HK-472AY	C CAPACITOR	4700PF 10% 50V	
C	883	NCB21HK-472AY	C CAPACITOR	4700PF 10% 50V	
C	CF801	VCF2M3B-105	C FILTER		
C	CF802	VCF2M3B-105	C FILTER		
C	CF871	CSB456F11	CELA LOCK		
C	CJ902	VMCO136-003	CONNECTOR		
C	CJ903	VMCO136-006	CONNECTOR		
C	CJ904	VMCO136-009	CONNECTOR		
C	CJ922	VMZ0015-014	POST PIN		
D	811	HVR100-10BTRF	VARI.CAP		
D	812	HVR100-10BTRF	VARI.CAP		
D	813	HVR100-10BTRF	VARI.CAP		
D	814	HVR100-10BTRF	VARI.CAP		
D	815	HVR100-10BTRF	VARI.CAP		
D	871	HSM2836C	DIODE		
D	872	MA153X	DIODE		
IC	IC801	U4290B	IC	DYNAS IC	
IC	IC802	NMX45935	IC	N.C & MPX	
L	803	VQP1002-4R7Y	INDUCTOR		
L	811	VQZ0072-001	IF COIL	700KHZ IF STAGE	
L	812	VQZ0072-001	IF COIL	700KHZ IF STAGE	
L	813	VQZ0072-001	IF COIL	700KHZ IF STAGE	
L	814	VQZ0072-001	IF COIL	700KHZ IF STAGE	
L	816	VQZ0076-001	PEAKING COIL	NOISE B.P.F	
L	817	VQZ0082-001	DET COIL	700KHZ DETECTOR	
Q	801	UN2213	TRANSISTOR		
Q	802	2SC2814(F4F5)HL	TRANSISTOR		
Q	803	2SC3661	TRANSISTOR		
Q	811	UN2213	TRANSISTOR		
Q	812	UN2213	TRANSISTOR		
R	801	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R	802	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W	
R	803	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R	804	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
R	805	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R	806	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R	807	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W	
R	811	NRSA02J-330NY	MG RESISTOR	33 5% 1/10W	
R	812	NRSA02J-270NY	MG RESISTOR	27 5% 1/10W	
R	813	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R	814	NRSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
R	815	NRSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
R	816	NRSA02J-183NY	MG RESISTOR	18K 5% 1/10W	
R	817	NRSA02J-681NY	MG RESISTOR	680 5% 1/10W	
R	818	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W	
R	819	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
R	820	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R	821	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W	
R	822	NRSA02J-561NY	MG RESISTOR	560 5% 1/10W	

Fig. 8-3

BLOCK NO. 0011111111


REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 823	NRSA02J-272NY	MG RESISTOR	2.7K 5% 1/10W	
R 825	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 826	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 827	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
R 828	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W	
R 829	NRSA02J-272NY	MG RESISTOR	2.7K 5% 1/10W	
R 830	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 831	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 832	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
R 851	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 852	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 871	NRSA02J-153NY	MG RESISTOR	15K 5% 1/10W	
R 872	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 873	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 875	NRSA02J-683NY	MG RESISTOR	68K 5% 1/10W	
R 876	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W	
R 877	NRSA02J-683NY	MG RESISTOR	68K 5% 1/10W	
R 878	NRSA02J-512NY	MG RESISTOR	5.1K 5% 1/10W	
R 879	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W	
TU 1	VAF2S07-301	FM FRONTEND		
VR811	NVP1412-301NZ	V RESISTOR	IF GAIN ADJ	
VR812	NVP1412-502NZ	V RESISTOR	MUTE LEVEL ADJ	
VR813	NVP1412-503NZ	V RESISTOR	MULTIPATH ADJ	
VR814	NVP1412-104NZ	V RESISTOR	NC1 LEVEL ADJ	
VR815	NVP1412-104NZ	V RESISTOR	NC2 LEVEL ADJ	
VR816	NVP1412-503NZ	V RESISTOR	NC3 LEVEL ADJ	
VR817	NVP1412-104NZ	V RESISTOR		
VR871	NVP1412-103NZ	V RESISTOR	SEPARATION ADJ	
VR872	NVP1412-103NZ	V RESISTOR	SNC HCC CONTROL	
X 811	VCM5048-001	CRYSTAL		


● AM Board Parts List

AM Board Parts List				BLOCK NO. 02			
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX			
C 51	NCB21EK-222AY	C CAPACITOR	2200PF 10% 25V				
C 52	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 53	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 56	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 57	NCB21HD-100AY	C CAPACITOR	10PF 50V				
C 58	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 59	NCB21HD-100AY	C CAPACITOR	10PF 50V				
C 60	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 61	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V				
C 62	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 63	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V				
C 64	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V				
C 65	QEK41CM-476	E CAPACITOR	47MF 20% 16V				
C 66	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V				
C 67	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V				
C 69	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V				
C 70	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V				
C 71	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V				
C 72	QEK41HM-105	E CAPACITOR	1.0MF 20% 50V				
C 73	QER40JM-226	E CAPACITOR	22MF 20% 6.3V				
C 74	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V				
C 75	NCT21CH-271AY	C CAPACITOR	270PF +50%-10%				
C 76	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V				
C 77	NCT21CH-431AY	C CAPACITOR	430PF +50%-10%				
C 78	NCB21EK-103AY	C CAPACITOR	.010MF 10% 25V				
C 79	QEK41CM-226	E CAPACITOR	22MF 20% 16V				
C 80	NCT21CH-120AY	C CAPACITOR	12PF +50%-10% 1				
C 81	NCT21CH-120AY	C CAPACITOR	12PF +50%-10% 1				
CF 51	BFU450C4N	CERAMIC FILTER					
CJ861	VMC0137-006	CONNECTOR					
CJ862	VMC0137-007	CONNECTOR					
CJ904	VMC0136-006	CONNECTOR					
CJ914	VMC0136-006	CONNECTOR					
CP861	VMC0135-006	CONNECTOR					
CP862	VMC0135-007	CONNECTOR					
D 51	DC010	SI DIODE					
D 52	HSM2838C	DIODE					
D 53	SVC321NP(B,D)3	VARI CAP					
D 54	SVC321NP(B,D)3	VARI CAP					
D 55	SVC321NP(B,D)3	VARI CAP					
D 56	HVM187STL	DIODE					
IC 51	LA1135	IC					
L 51	VGP1002-4R7Y	INDUCTOR					
L 52	VGP1003-6R8Y	INDUCTOR					
L 53	VGP2031-001	MW RF					
L 54	VGP2031-101	MW RF					
L 55	VGP20056-001	LW RF					
L 56	VGP20056-001	LW RF					

[illegible]

■ Main Board





● Main Board Parts List

A	REF.	BLOCK NO. 03			REMARKS	SUFFIX
		PARTS NO.	PARTS NAME	PARTS NO.		
	C 101	NCS21HJ-471AY	E CAPACITOR	470PF 5% 50V		
	C 102	QERF1HM-4742M	E CAPACITOR	.47MF 20% 50V		
	C 103	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		
	C 104	QFV71HJ-103	TF CAPACITOR	.010MF 5% 50V		
	C 105	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 106	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 121	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 131	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 151	QFV81HJ-473	TF CAPACITOR	.047MF 5% 50V		
	C 152	QFV81HJ-473	TF CAPACITOR	.047MF 5% 50V		
	C 153	NCB21HK-332AY	C CAPACITOR	3300PF 10% 50V		
	C 154	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 155	NCT21CH-270AY	C CAPASITOR	27PF +50:-10% 1		
	C 162	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 163	NCB21HK-152AY	C CAPACITOR	1500PF 10% 50V		
	C 164	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 165	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 166	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 167	QER41HM-334VM	E CAPACITOR	.33MF 20% 50V		
	C 168	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 169	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 170	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 172	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 173	NCS21HJ-101AY	C CAPACITOR	100PF 5% 50V		
	C 174	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		
	C 175	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 192	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 193	NCS21HJ-101AY	C CAPACITOR	100PF 5% 50V		
	C 194	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		
	C 195	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 201	NCS21HJ-171AY	E CAPACITOR	470PF 5% 50V		
	C 202	QERF1HM-4742M	E CAPACITOR	.47MF 20% 50V		
	C 203	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		
	C 204	QFV71HJ-103	TF CAPACITOR	.010MF 5% 50V		
	C 205	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 206	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 221	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 231	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 251	QFV81HJ-473	TF CAPACITOR	.047MF 5% 50V		
	C 252	QFV81HJ-473	TF CAPACITOR	.047MF 5% 50V		
	C 253	NCB21HK-332AY	C CAPACITOR	3300PF 10% 50V		
	C 254	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 255	NCT21CH-270AY	C CAPASITOR	27PF +50:-10% 1		
	C 262	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 263	NCB21HK-152AY	C CAPACITOR	1500PF 10% 50V		
	C 264	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 265	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 266	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 267	QER41HM-334VM	E CAPACITOR	.53MF 20% 50V		
	C 268	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 269	QER41CM-106M	E CAPACITOR	10MF 20% 16V		
	C 270	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 272	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 273	NCS21HJ-101AY	C CAPACITOR	100PF 5% 50V		
	C 274	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		

BLOCK NO. 03

A	REF.	BLOCK NO. 03			REMARKS	SUFFIX
		PARTS NO.	PARTS NAME	PARTS NO.		
	C 275	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 292	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 293	NCS21HJ-101AY	C CAPACITOR	100PF 5% 50V		
	C 294	NCS21HJ-680AY	C CAPACITOR	68PF 5% 50V		
	C 295	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 341	NCS21HJ-331AY	C CAPACITOR	330PF 5% 50V		
	C 441	NCS21HJ-331AY	C CAPACITOR	330PF 5% 50V		
	C 481	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V		
	C 530	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V		
	C 531	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 532	NCF21EZ-563AY	C CAPACITOR	.056MF +80:-20%		
	C 533	NCB21HK-273AY	C CAPACITOR	.027MF 10% 50V		
	C 534	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V		
	C 535	NCB21HK-273AY	E CAPACITOR	.027MF 10% 50V		
	C 536	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V		
	C 539	QERF0JM-107ZN	E CAPACITOR	100MF 20% 6.3V		
	C 541	NCB21HK-123AY	C CAPACITOR	.010MF 10% 50V		
	C 581	NCB21HK-103AY	C CAPACITOR	.012MF 10% 50V		
	C 701	VCE0040-001	E CAPACITOR	.010MF 10% 50V		
	C 702	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V		
	C 703	NCT21CH-120AY	C CAPACITOR	12PF +50:-10% 1		
	C 704	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V		
	C 705	NCF21EZ-104AY	C CAPACITOR	.10MF +80:-20%		
	C 706	QER40JM-226	E CAPACITOR	22MF 20% 6.3V		
	C 707	NCF21EZ-104AY	C CAPACITOR	.10MF +80:-20%		
	C 708	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V		
	C 709	QER41CM-476M	E CAPACITOR	47MF 20% 16V		
	C 710	QER41CM-476M	E CAPACITOR	47MF 20% 16V		
	C 711	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V		
	C 712	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V		
	C 713	QERF1CM-1072M	E CAPACITOR	100MF 20% 16V		
	C 714	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V		
	C 715	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V		
	C 716	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V		
	C 718	NCB21HK-103AY	C CAPACITOR	.010MF 10% 50V		
	C 719	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V		
	C 761	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V		
	C 781	NCT21CH-220AY	C CAPACITOR	22PF +50:-10% 1		
	C 782	NCT21CH-220AY	C CAPACITOR	22PF +50:-10% 1		
	C 783	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V		
	C 784	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 785	NCB21HK-102AY	E CAPACITOR	1000PF 10% 50V		
	C 786	QER41CM-476M	E CAPACITOR	47MF 20% 16V		
	C 787	QER41HM-225	E CAPACITOR	2.2MF 20% 50V		
	C 790	NCT21CH-270AY	C CAPASITOR	27PF +50:-10% 1		
	C 791	NPSA02J-ORONY	MG RESISTOR	5% 1/10W		
	C 901	QERF1CM-1072M	E CAPACITOR	100MF 20% 16V		
	C 902	QCC11EM-103V	C CAPACITOR	.010MF 20% 25V		
	C 911	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V		
	C 912	NCB21HK-272AY	C CAPACITOR	2700PF 10% 50V		
	C 913	NCB21HK-472AY	C CAPACITOR	4700PF 10% 50V		
	C 914	QER41HM-104M	E CAPACITOR	.10MF 20% 50V		
	C 915	QER41HM-224VS	E CAPACITOR	.22MF 20% 50V		
	C 916	QERF1HM-335ZN	E CAPACITOR	3.3MF 20% 50V		

BLOCK NO. 03				
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 917	QER41CM-226VM	E CAPACITOR	22MF 20% 16V	
C 918	QER41CM-476M	E CAPACITOR	47MF 20% 16V	
C 921	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V	
C 922	QER40JM-226	E CAPACITOR	22MF 20% 6.3V	
C 923	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V	
C 924	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V	
C 931	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V	
C 932	QER40JM-226	E CAPACITOR	22MF 20% 6.3V	
C 933	QERF0JM-476ZN	E CAPACITOR	47MF 20% 6.3V	
C 934	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V	
C 941	QER41CM-476M	E CAPACITOR	47MF 20% 16V	
C 942	QER41CM-476M	E CAPACITOR	47MF 20% 16V	
C 943	QER41HM-225	E CAPACITOR	2.2MF 20% 50V	
C 944	NCF21EZ-104AY	C CAPACITOR	.10MF +80%-20%	
C 962	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	
C 963	QER41CM-476M	E CAPACITOR	47MF 20% 16V	
C 964	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V	
C 966	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V	
C 967	NCB21HK-223AY	C CAPACITOR	.022MF 10% 50V	
C 968	QER41CM-476M	E CAPACITOR	47MF 20% 16V	
C 971	QERF0JM-107ZN	E CAPACITOR	100MF 20% 6.3V	
C 972	NCB21HK-473AY	E CAPACITOR	.047MF 10% 50V	
C 991	QERF0JM-107ZN	E CAPACITOR	100MF 20% 6.3V	
C 992	NCB21HK-473AY	C CAPACITOR	.047MF 10% 50V	
CN901	VMC0135-003	CONNECTOR	FM P.W.B.	
CN902	VMC0135-006	CONNECTOR	FM P.W.B.	
CN903	VMC0135-009	CONNECTOR	FM P.W.B.	
CN904	VMC0135-006	CONNECTOR	AM P.W.B.	
CN906	VMC0135-015	CONNECTOR	DOLBY P.W.B.	
CN913	EMV7901-015	CONNECTOR	TO NOSE ASS'Y	
CN914	VMC0135-006	CONNECTOR	AM P.W.B.	
CN941	VGZ0007-020	FEED THRU CONNE		
CP521	VMC0135-006	CONNECTOR		
CP531	VMC0063-004	CONNECTOR	SUB WOOFER	
CP532	VMC0135-012	CONNECTOR	DOLBY P.W.B.	
CP701	VMC0135-003	CONNECTOR	OPEN SOL	
CP702	VMC0075-004N	CONNECTOR	RESET SW	
CP703	VMC0075-002N	CONNECTOR	OPEN	
CP931	VMC0063-005	CONNECTOR	LINE IN	
CP971	VMC0063-008	CONNECTOR	LINE OUT	
D 341	HSM2838C	DIODE		
D 441	HSM2838C	DIODE		
D 531	MA3039(L)	Z DIODE		
D 532	HSM2838C	DIODE		
D 533	HSM2838C	DIODE		
D 581	HSM2836C	DIODE		
D 582	HSM2836C	DIODE		
D 700	MA165	SI DIODE		
D 705	MA165	SI DIODE		
D 707	MA165	SI DIODE		
D 709	MA165	SI DIODE		
D 710	MA165	SI DIODE		
D 711	MA3056	Z DIODE		
D 712	HSM2838C	DIODE	2P 2 1M3	
D 713	HSM2838C	DIODE	SD	

BLOCK NO. 03				
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
D 715	MA3091(H)	Z DIODE	MUTE	
D 716	HSM2838C	DIODE	RESET	
D 717	HSM2838C	DIODE	LOCAL	
D 718	HSM2838C	DIODE	RADIO	
D 719	RL252	S DIODE	SOL	
D 720	MA165	SI DIODE	OPEN	
D 721	HSM2836C	DIODE	RESET MUTE	
D 722	HSM2838C	DIODE		
D 723	MA165	SI DIODE		
D 761	HSM2838C	DIODE		
D 781	MA3100(L)	ZENER DIODE		
D 785	HSM2838C	DIODE		
D 786	HSM2838C	DIODE		
D 787	HSM2836C	DIODE		
D 788	HSM2836C	DIODE		
D 921	MA3031(L)	Z DIODE		
D 931	MA3031(L)	Z DIODE		
D 941	MA3091(H)	Z DIODE		
D 942	11ES2	SI DIODE		
D 943	11ES2	SI DIODE		
D 944	MA3056	Z DIODE		
D 945	11ES2	SI DIODE		
D 947	11ES2	SI DIODE		
D 948	HSM2838C	DIODE		
D 949	MA3039(L)	Z DIODE		
D 950	MA165	SI DIODE		
D 961	HSM2838C	DIODE		
D 971	MA3047(M)X	Z DIODE		
D 972	HSM2838C	DIODE		
D 973	HSM2836C	DIODE		
D 974	HSM2836C	DIODE		
D 991	MA3047(M)X	Z DIODE		
D 992	HSM2838C	DIODE		
IC161	M5228FP	IC		
IC261	M5228FP	IC		
IC531	NJM4565M	IC		
IC701	UPD75116GF-E74	IC		
IC761	MC14081BCP	IC		
IC781	LM7000	IC		
IC901	UPC1228HA	IC		
IC911	LA2000S	IC		
IC921	NJM4565M	IC		
IC931	NJM4565M	IC		
IC961	LC7537N	IC		
IC962	AN6556S	IC CMOS		
IC971	AN6558S	MINI FLAT IC		
IC991	AN6558S	MINI FLAT IC		
L 701	VQ025K-101	INDUCTOR		
Q 101	2SB709(Q,R)	TRANSISTOR		
Q 171	2SD1048X-6HL	TRANSISTOR		
Q 191	2SD1048X-6HL	TRANSISTOR		
Q 201	2SB709(Q,R)	TRANSISTOR		
Q 271	2SD1048X-6HL	TRANSISTOR		
Q 291	2SD1048X-6HL	TRANSISTOR		
Q 531	2SD1048X-6HL	TRANSISTOR		

BLOCK NO. 03

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
Q 532	UN2111	TRANSISTOR		
Q 533	UN2111	TRANSISTOR		
Q 534	2SD1048X-6HL	TRANSISTOR		
Q 581	UN2213	TRANSISTOR		
Q 582	2SD601A(RS)	TRANSISTOR		
Q 701	UN2213	TRANSISTOR		
Q 703	2SB709(Q,R)	TRANSISTOR		
Q 704	UN2111	TRANSISTOR		
Q 705	2SD601A(RS)	TRANSISTOR		
Q 706	2SD601A(RS)	TRANSISTOR		
Q 708	UN2213	TRANSISTOR		
Q 709	2SD601A(RS)	TRANSISTOR		
Q 710	2SD601A(RS)	TRANSISTOR		
Q 711	2SD601A(RS)	TRANSISTOR		
Q 714	2SD601A(RS)	TRANSISTOR		
Q 715	2SB1322(RS)	TRANSISTOR		
Q 716	2SB1322(RS)	TRANSISTOR		
Q 720	UN2111	TRANSISTOR		
Q 722	2SD882(P,Q)	TRANSISTOR		
Q 723	2SB1322(RS)	TRANSISTOR		
Q 724	2SD601A(RS)	TRANSISTOR		
Q 725	2SD1994(R,S)	TRANSISTOR		
Q 726	UN2213	TRANSISTOR		
Q 727	2SD601A(RS)	TRANSISTOR		
Q 771	2SA1362GR	TRANSISTOR		
Q 772	2SB709(Q,R)	TRANSISTOR		
Q 773	2SD601A(RS)	TRANSISTOR		
Q 774	2SD601A(RS)	TRANSISTOR		
Q 775	2SB709(Q,R)	TRANSISTOR		
Q 892	UN2211	TRANSISTOR		
Q 901	UN2213	TRANSISTOR	METAL	
Q 911	2SD601A(RS)	TRANSISTOR		
Q 912	2SK303(V2,V3)	FET		
Q 941	2SB815B7-T-HL	TRANSISTOR		
Q 942	2SD1994(R,S)	TRANSISTOR		
Q 943	2SB815B7-T-HL	TRANSISTOR		
Q 944	UN2213	TRANSISTOR		
Q 945	2SD601A(RS)	TRANSISTOR		
Q 946	2SD1266(P,Q)	TRANSISTOR		
Q 949	2SD1994(R,S)	TRANSISTOR		
Q 950	2SB709(Q,R)	TRANSISTOR		
Q 951	2SB709(Q,R)	TRANSISTOR		
Q 952	UN2213	TRANSISTOR		
Q 961	2SD601A(RS)	TRANSISTOR		
R 101	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W	
R 102	NRSA02J-822NY	MG REAIATOR	8.2K 5% 1/10W	
R 103	NRSA02J-121NY	MG RESISTOR	120 5% 1/10W	
R 104	NRSA02J-622NY	MG RESISTOR	6.2K 5% 1/10W	
R 105	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 106	NRSA02J-OR0NY	MG RESISTOR	5% 1/10W	
R 121	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 122	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 123	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 124	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 125	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	

BLOCK NO. 03


REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 126	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 127	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 131	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 132	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 133	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 134	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 135	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 136	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 137	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 141	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 162	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
R 163	NRSA02J-105NY	MG RESISTOR	1.0M 5% 1/10W	
R 164	NRSA02J-103NY	MG RESISTOR	1.0M 5% 1/10W	
R 165	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 166	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W	
R 167	NRSA02J-105NY	MG RESISTOR	1.0M 5% 1/10W	
R 168	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 169	NRSA02J-OR0NY	MG RESISTOR	5% 1/10W	
R 171	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 172	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 173	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 174	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 175	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 176	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W	
R 177	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 178	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W	
R 191	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 192	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 195	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 196	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W	
R 197	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 198	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W	
R 201	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W	
R 202	NRSA02J-822NY	MG REAIATOR	8.2K 5% 1/10W	
R 203	NRSA02J-121NY	MG RESISTOR	120 5% 1/10W	
R 204	NRSA02J-622NY	MG RESISTOR	6.2K 5% 1/10W	
R 205	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 206	NRSA02J-OR0NY	MG RESISTOR	5% 1/10W	
R 221	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 222	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 223	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 224	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 225	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 226	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 227	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 231	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 232	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 233	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 234	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 235	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 236	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 237	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
R 261	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 262	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
R 263	NRSA02J-105NY	MG RESISTOR	1.0M 5% 1/10W	

BLOCK NO. 03						BLOCK NO. 03					
A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	R 264	NRSA02J-105NY	MG RESISTOR	1.0M 5% 1/10W			R 710	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 265	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W			R 711	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 266	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W			R 712	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 267	NRSA02J-105NY	MG RESISTOR	1.0M 5% 1/10W			R 713	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
	R 268	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W			R 714	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 269	NRSA02J-OR0NY	MG RESISTOR	5% 1/10W			R 715	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 271	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 716	NRSA02J-182NY	MG RESISTOR	1.8K 5% 1/10W	
	R 272	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 717	NRSA02J-182NY	MG RESISTOR	1.8K 5% 1/10W	
	R 273	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W			R 718	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 274	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W			R 719	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 275	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 720	NRSA02J-182NY	MG RESISTOR	1.8K 5% 1/10W	
	R 276	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W			R 721	NRSA02J-392NY	MG RESISTOR	3.9K 5% 1/10W	
	R 277	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W			R 723	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 278	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W			R 724	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 291	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 725	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
	R 292	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 726	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 295	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 727	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W	
	R 296	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W			R 728	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 297	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W			R 729	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 298	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W			R 730	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
	R 331	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 731	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
	R 341	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W			R 732	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W	
	R 342	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W			R 733	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 431	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 734	NRSA02J-392NY	MG RESISTOR	3.9K 5% 1/10W	
	R 441	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W			R 735	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 442	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W			R 736	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 530	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W			R 737	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 531	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 738	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 532	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W			R 739	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 533	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W			R 740	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	
	R 534	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 741	NRSA02J-392NY	MG RESISTOR	3.9K 5% 1/10W	
	R 535	NRSA02J-153NY	MG RESISTOR	15K 5% 1/10W			R 742	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 536	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 743	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 537	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W			R 745	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
	R 538	NRSA02J-183NY	MG RESISTOR	18K 5% 1/10W			R 746	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	R 539	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W			R 747	QRD14AJ-102Y	C-RESISTOR	1.0K 5% 1/4W	
	R 540	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W			R 748	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
	R 541	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W			R 749	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 549	NRSA02J-101NY	MG RESISTOR	100 5% 1/10W			R 750	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
	R 581	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 751	QRG019J-181A	OMF RESISTOR	180 5% 1/1W	
	R 582	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 752	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	R 583	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W			R 753	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
	R 584	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W			R 754	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W	
	R 585	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W			R 756	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
	R 586	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W			R 757	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 587	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W			R 758	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
	R 701	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 759	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
	R 702	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 760	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
	R 703	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 761	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 704	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 762	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
	R 705	NRSA02J-682NY	MG RESISTOR	6.8K 5% 1/10W			R 763	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
	R 706	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 764	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
	R 707	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W			R 765	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 708	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W			R 766	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
	R 709	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W			R 767	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	

BLOCK NO. 03					BLOCK NO. 03				
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX					
R 768	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 770	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 771	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						
R 772	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						
R 780	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 781	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W						
R 782	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W						
R 783	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 784	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 785	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 786	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W						
R 787	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W						
R 788	NRSA02J-471NY	MG RESISTOR	470 5% 1/10W						
R 789	NRSA02J-471NY	MG RESISTOR	470 5% 1/10W						
R 790	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 791	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 792	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 793	NRSA02J-471NY	MG RESISTOR	470 5% 1/10W						
R 794	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 795	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W						
R 796	NRSA02J-333NY	MG RESISTOR	33K 5% 1/10W						
R 799	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 801	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W						
R 802	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W						
R 803	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 804	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						
R 805	NRSA02J-121NY	MG RESISTOR	120 5% 1/10W						
R 901	NRSA02J-682NY	MG RESISTOR	6.8K 5% 1/10W						
R 902	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W						
R 903	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 912	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 913	NRSA02J-330NY	MG RESISTOR	33 5% 1/10W						
R 914	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 915	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W						
R 916	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W						
R 917	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 918	NRSA02J-334NY	MG RESISTOR	330K 5% 1/10W						
R 919	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 920	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 921	NRSA02J-681NY	MG RESISTOR	680 5% 1/10W						
R 923	NRSA02J-100NY	MG RESISTOR	10 5% 1/10W						
R 924	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 931	NRSA02J-681NY	MG RESISTOR	680 5% 1/10W						
R 933	NRSA02J-100NY	MG RESISTOR	10 5% 1/10W						
R 934	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 940	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W						
R 941	NRSA02J-330NY	MG RESISTOR	33 5% 1/10W						
R 942	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W						
R 943	NRSA02J-272NY	MG RESISTOR	2.7K 5% 1/10W						
R 944	NRSA02J-822NY	MG REAIATOR	8.2K 5% 1/10W						
R 945	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W						
R 946	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W						
R 947	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W						
R 948	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						
R 949	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W						

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 950	NRSA02J-152NY	MG RESISTOR	1.5K 5% 1/10W	
R 951	ORD161J-221	CARBON RESISTOR	220 5% 1/6W	
R 952	NRSA02J-392NY	MG RESISTOR	3.9K 5% 1/10W	
R 953	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 954	ORD161J-1R0	CARBON RESISTOR	1.0 5% 1/6W	
R 957	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 958	NRSA02J-332NY	MG RESISTOR	3.3K 5% 1/10W	
R 959	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 960	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 961	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 962	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 963	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 964	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 965	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 966	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 967	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 968	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
R 969	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
R 971	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
R 991	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
RY942	VSK1012-118	RELAY		
TC701	QAT3722-200ZM	T CAPACITOR		
TP704	VMC0075-003N	CONNECTOR		
TP705	VMC0075-003N	CONNECTOR		
VR701	VCV5012-223	SEMI V RESISTOR		
X 701	VCX5024-001	CRYSTAL		
X 781	VCX5025-001	CRYSTAL		

■ DOLBY NR Board



● DOLBY NR Board Parts List

	A	REF.	PARTS NO.	PART'S NAME	REMARKS	SUFFIX
		C 301	GFN41HJ-332	M CAPACITOR	3300PF 5% 50V	
		C 302	GER41HM-105VM	E CAPACITOR	1.0MF 20% 50V	
		C 303	GFN41HJ-222	M CAPACITOR	2200PF 5% 50V	
		C 304	GFN41HJ-222	M CAPACITOR	2200PF 5% 50V	
		C 305	GERF1HM-564ZM	E CAPACITOR	.56MF 20% 50V	
		C 306	GER41HM-334VM	E CAPACITOR	.33MF 20% 50V	
		C 307	GER41HM-105VM	E CAPACITOR	1.0MF 20% 50V	
		C 311	GER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	
		C 312	GER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	
		C 321	GER41CM-106M	E CAPACITOR	10MF 20% 16V	
		C 401	GFN41HJ-332	M CAPACITOR	3300PF 5% 50V	
		C 402	GER41HM-105VM	E CAPACITOR	1.0MF 20% 50V	
		C 403	GFN41HJ-222	M CAPACITOR	2200PF 5% 50V	
		C 404	GFN41HJ-222	M CAPACITOR	2200PF 5% 50V	
		C 405	GERF1HM-564ZM	E CAPACITOR	.56MF 20% 50V	
		C 406	GER41HM-334VM	E CAPACITOR	.33MF 20% 50V	
		C 407	GER41HM-105VM	E CAPACITOR	1.0MF 20% 50V	
		C 411	GER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	
		C 412	GER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	
		C 421	GER41CM-106M	E CAPACITOR	10MF 20% 16V	
		C 501	GER41CM-106M	E CAPACITOR	10MF 20% 16V	
		C 502	GER41CM-106M	E CAPACITOR	10MF 20% 16V	
		C 503	GER41CM-476M	E CAPACITOR	47MF 20% 16V	
		C 511	NCB21EK-473AY	C CAPACITOR	.047MF 10% 25V	
		C 512	GER41CM-106M	E CAPACITOR	10MF 20% 16V	
		CJ531	VMCO136-003	CONNECTOR		
		CJ532	VMCO136-012	CONNECTOR		
		CJ906	VMCO136-015	CONNECTOR		
		CP511	VMCO064-006	CONNECTOR	CHANGER	
		CP512	VMCO064-004	CONNECTOR	CHANGER	
		D 511	HSM2836C	DIODE		
		D 512	MA3039(L)	Z DIODE		
		D 650	LN41YCPH	LED		
		IC501	CXA1332M	IC		
		IC511	UPD4052BG	IC		
		Q 311	2SD1048X-6HL	TRANSISTOR		
		Q 411	2SD1048X-6HL	TRANSISTOR		
		Q 511	UN2213	TRANSISTOR		
		R 301	NRSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
		R 302	NRSA02J-183NY	MG RESISTOR	18K 5% 1/10W	
		R 303	NRSA02J-243NY	EC CAPACITOR	24K 5% 1/10W	
		R 304	NPSA02J-561NY	MG RESISTOR	560 5% 1/10W	
		R 311	NPSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
		R 312	NPSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
		R 313	NPSA02J-153NY	MG RESISTOR	15K 5% 1/10W	
		R 314	NPSA02J-393NY	MG RESISTOR	39K 5% 1/10W	
		R 315	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
		R 316	NPSA02J-183NY	MG RESISTOR	18K 5% 1/10W	
		R 317	NPSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
		R 318	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
		R 319	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
		R 401	NRSA02J-123NY	MG RESISTOR	12K 5% 1/10W	
		R 402	NRSA02J-183NY	MG RESISTOR	18K 5% 1/10W	
		R 403	NPSA02J-243NY	EC CAPACITOR	24K 5% 1/10W	
		R 404	NPSA02J-561NY	MG RESISTOR	560 5% 1/10W	
		R 411	NRSA02J-123NY	MG RESISTOR	12K 5% 1/10W	

A	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
	R 412	NRSA02J-153NY	MG RESISTOR	15K 5% 1/10W	
	R 413	NRSA02J-393NY	MG RESISTOR	39K 5% 1/10W	
	R 414	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 415	NRSA02J-183NY	MG RESISTOR	18K 5% 1/10W	
	R 416	NRSA02J-104NY	MG RESISTOR	100K 5% 1/10W	
	R 417	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	
	R 418	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
	R 501	NRSA02J-682NY	MG RESISTOR	6.8K 5% 1/10W	
	R 502	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
	R 503	NRSA02J-273NY	MG RESISTOR	27K 5% 1/10W	
	R 511	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	R 512	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	R 513	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W	
	R 797	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	R 798	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
	S 531	GSP1A11-V06A	TACT SWITCH	RESET	
	TP501	VMC0075-R02N	CONNECTOR		
	VR301	QVPA603-223A	SEMI.V.RESISTOR		
	VR302	QVPA603-223A	SEMI.V.RESISTOR		
	VR401	QVPA603-223A	SEMI.V.RESISTOR		
	VR402	QVPA603-223A	SEMI.V.RESISTOR		

■ Indicator/Switch Board




Fig. 8-12




Fig. 8-13

● Indicator/Switch Board Parts List

BLOCK NO. 05					BLOCK NO. 05				
REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX	REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 601	NCT21CH-220AY	C CAPACITOR	22PF +50%-10% 1		R 610	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
C 602	NCT21CH-220AY	C CAPACITOR	22PF +50%-10% 1		R 611	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
C 603	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V		R 612	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
C 604	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V		R 613	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
C 605	QER40JM-476VM	C CAPACITOR	47MF 20% 6.3V		R 614	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
C 606	NC521HJ-681AY	C CAPACITOR	680PF 5% 50V		R 615	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
C 607	NCB21EK-223AY	C CAPACITOR	.022MF 10% 25V		R 617	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
C 608	QER40JM-476VM	C CAPACITOR	47MF 20% 6.3V		R 618	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
C 609	QEF81AM-475W	TS-E-CAPACITOR	4.7MF 20% 10V		R 620	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
CJ601	VNJ4022-001	JACK	AUX JACK		R 621	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
CN601	VNC0222-015N	CONNECTOR			R 622	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 601	HSM2838C	DIODE			R 623	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 602	HSM2838C	DIODE			R 624	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 603	LN02102C46-LF2	LED	TWO COLORS LED		R 625	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 604	LN02102C46-LF2	LED	TWO COLORS LED		R 626	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 605	LN02102C46-LF2	LED	TWO COLORS LED		R 627	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 606	LN02102C46-LF2	LED	TWO COLORS LED		R 628	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 607	LN02102C46-LF2	LED	TWO COLORS LED		R 629	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 608	LN02102C46-LF2	LED	TWO COLORS LED		R 630	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 609	LN02102C46-LF2	LED	TWO COLORS LED		R 631	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 610	LN02102C46-LF2	LED	TWO COLORS LED		R 632	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 611	LN02102C46-LF2	LED	TWO COLORS LED		R 633	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 612	LN02102C46-LF2	LED	TWO COLORS LED		R 634	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 613	LN02102C46-LF2	LED	TWO COLORS LED		R 635	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
D 614	LN02102C46-LF2	LED	TWO COLORS LED		R 636	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 615	LN02102C46-LF2	LED	TWO COLORS LED		R 637	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 616	LN02102C46-LF2	LED	TWO COLORS LED		R 638	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
D 617	LN02102C46-LF2	LED	TWO COLORS LED		R 639	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
D 618	LN02102C46-LF2	LED	TWO COLORS LED		R 645	NRSA02J-221NY	MG RESISTOR	220 5% 1/10W	
D 619	LN02102C46-LF2	LED	TWO COLORS LED		S 601	QSPIA11-V15	TACT SWITCH		
D 620	LN02102C46-LF2	LED	TWO COLORS LED		S 602	QSPIA11-V06A	TACT SWITCH		
IC601	UP07500468-687	IC			S 603	QSPIA11-V06A	TACT SWITCH		
IC602	LC7582A	IC			S 604	QSPIA11-V06A	TACT SWITCH		
IC603	BX-1408	IC			S 605	QSPIA11-V06A	TACT SWITCH		
L 601	VQP0018-101	INDUCTOR			S 606	QSPIA11-V06A	TACT SWITCH		
LCD 1	VGL1092-002	LCD			S 607	QSPIA11-V06A	TACT SWITCH		
PL601	VGZ0001-037	LAMP			S 608	QSPIA11-V06A	TACT SWITCH		
PL602	VGZ0001-037	LAMP			S 609	QSPIA11-V06A	TACT SWITCH		
PL603	VGZ0001-037	LAMP			S 610	QSPIA11-V06A	TACT SWITCH		
PL604	VGZ0001-037	LAMP			S 611	QSPIA11-V06A	TACT SWITCH		
PL611	VGZ0001-038	LAMP			S 612	QSPIA11-V06A	TACT SWITCH		
PL612	VGZ0001-038	LAMP			S 613	QSPIA11-V06A	TACT SWITCH		
PL613	VGZ0001-038	LAMP			S 614	QSPIA11-V06A	TACT SWITCH		
PL614	VGZ0001-038	LAMP			S 615	QSPIA11-V06A	TACT SWITCH		
PL615	VGZ0001-038	LAMP			S 616	QSPIA11-V06A	TACT SWITCH		
Q 601	UN211	TRANSISTOR			S 617	QSPIA11-V06A	TACT SWITCH		
R 601	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W		S 618	QSPIA11-V06A	TACT SWITCH		
R 602	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W		S 619	QSPIA11-V06A	TACT SWITCH		
R 603	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W		S 620	QSPIA11-V06A	TACT SWITCH		
R 604	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W		S 621	QSPIA11-V06A	TACT SWITCH		
R 605	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W		S 622	QSPIA11-V06A	TACT SWITCH		
R 606	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W		X 601	VCX5024-001	CRYSTAL		
R 607	NRSA02J-102NY	MG RESISTOR	1.0K 5% 1/10W						
R 608	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						
R 609	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W						

BLOCK NO. 05

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
R 610	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 611	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 612	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 613	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 614	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 615	NRSA02J-103NY	MG RESISTOR	10K 5% 1/10W	
R 617	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	
R 618	NRSA02J-223NY	MG RESISTOR	22K 5% 1/10W	
R 620	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 621	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 622	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 623	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 624	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 625	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 626	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 627	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 628	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 629	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 630	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 631	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 632	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 633	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 634	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 635	NRSA02J-271NY	MG RESISTOR	270 5% 1/10W	
R 636	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 637	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 638	NRSA02J-391NY	MG RESISTOR	390 5% 1/10W	
R 639	NRSA02J-331NY	MG RESISTOR	330 5% 1/10W	
R 645	NRSA02J-221NY	MG RESISTOR	220 5% 1/10W	
S 601	QSPIA11-V15	TACT SWITCH		
S 602	QSPIA11-V06A	TACT SWITCH		
S 603	QSPIA11-V06A	TACT SWITCH		
S 604	QSPIA11-V06A	TACT SWITCH		
S 605	QSPIA11-V06A	TACT SWITCH		
S 606	QSPIA11-V06A	TACT SWITCH		
S 607	QSPIA11-V06A	TACT SWITCH		
S 608	QSPIA11-V06A	TACT SWITCH		
S 609	QSPIA11-V06A	TACT SWITCH		
S 610	QSPIA11-V06A	TACT SWITCH		
S 611	QSPIA11-V06A	TACT SWITCH		
S 612	QSPIA11-V06A	TACT SWITCH		
S 613	QSPIA11-V06A	TACT SWITCH		
S 614	QSPIA11-V06A	TACT SWITCH		
S 615	QSPIA11-V06A	TACT SWITCH		
S 616	QSPIA11-V06A	TACT SWITCH		
S 617	QSPIA11-V06A	TACT SWITCH		
S 618	QSPIA11-V06A	TACT SWITCH		
S 619	QSPIA11-V06A	TACT SWITCH		
S 620	QSPIA11-V06A	TACT SWITCH		
S 621	QSPIA11-V06A	TACT SWITCH		
S 622	QSPIA11-V06A	TACT SWITCH		
X 601	VCX5024-001	CRYSTAL		

■ **SK/DK Board (G/GE version only)**




Fig. 8-14

● SK/DK Board Parts List

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
B 558	NRSA02J-ORONY	MG RESISTOR	5% 1/10W	G-GE
C 521	QER41CM-476M	E CAPACITOR	47MF 20% 16V	G-GE
C 522	QER41HM-105VM	E CAPACITOR	1.0MF 20% 50V	G-GE
C 525	QFV81HJ-683	TF CAPACITOR	-0.68MF 5% 50V	G-GE
C 526	QER41EM-475VM	E CAPACITOR	4.7MF 20% 25V	G-GE
C 527	QER41CM-226VM	E CAPACITOR	22MF 20% 16V	G-GE
C 531	QER41CM-476M	E CAPACITOR	47MF 20% 16V	G-GE
C 532	QER41CM-106M	E CAPACITOR	10MF 20% 16V	G-GE
C 533	QER41CM-106M	E CAPACITOR	10MF 20% 16V	G-GE
C 534	QER41CM-226VM	E CAPACITOR	22MF 20% 16V	G-GE
C 535	QER41CM-106M	E CAPACITOR	10MF 20% 16V	G-GE
CF531	CSB456F11	CELA LOCK		G-GE
CJ521	VMC0136-006	CONNECTOR		G-GE
D 551	HSM2838C	DIODE		G-GE
IC521	AN7410N	IC	DK	G-GE
IC531	SK62053	IC	SK	G-GE
R 521	NRSA02J-470NY	MG RESISTOR	47 5% 1/10W	G-GE
R 522	NRSA02J-243NY	EC CAPACITOR	24K 5% 1/10W	G-GE
R 523	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	G-GE
R 524	NRSA02J-472NY	MG RESISTOR	4.7K 5% 1/10W	G-GE
R 532	NRSA02J-473NY	MG RESISTOR	47K 5% 1/10W	G-GE
R 533	NRS181J-470NY	MG RESISTOR	47 5% 1/8W	G-GE
R 534	NRSA02J-330NY	MG RESISTOR	33 5% 1/10W	G-GE
R 535	NRSA02J-222NY	MG RESISTOR	2.2K 5% 1/10W	G-GE
TP531	VMZ0015-002	POST PIN		G-GE
VR521	VCV5015-682	V RESISTOR		G-GE

■ Mechanism Switch/Sensor Board

■ Drive Board




Fig. 8-15




Fig. 8-16




Fig. 8-17

● Mechanism Switch/Sensor Board Parts List

REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
CP801	VMC0064-013	CONNECTOR		
CP802	VMC0064-003	CONNECTOR		
Q 801	NJL5163K(A,B)	PHOTO CAPLOR		
Q 802	NJL5163K(A,B)	PHOTO CAPLOR		
R 801	QRD161J-681	C RESISTOR	680 5% 1/6W	
S 801	QSP2K21-V01	PUSH SWITCH		
S 802	QSP2K21-V01	PUSH SWITCH		
S 803	VSH1153-001	SWITCH		

● Drive Board Parts List


REF.	PARTS NO.	PARTS NAME	REMARKS	SUFFIX
C 852	QCVB1CN-103Y	C CAPACITOR	.010MF 20% 16V	
C 854	QCVB1CN-103Y	C CAPACITOR	.010MF 20% 16V	
C 855	QER41CN-106M	E CAPACITOR	10MF 20% 16V	
C 856	QER41CN-226VM	E CAPACITOR	22MF 20% 16V	
CP852	VMC0064-007	CONNECTOR		
D 851	MA4068(L)	Z DIODE		
D 853	HSS104TJ	SI DIODE		
IC851	LB1648	IC		
Q 851	2SD1994(R,S)	TRANSISTOR		
Q 852	2SD1994(R,S)	TRANSISTOR		
R 852	QRD161J-822	CARBON RESISTOR	8.2K 5% 1/6W	
R 853	QRD121J-100	CARBON RESISTOR	10 5% 1/2W	
R 854	QRD161J-104	CARBON RESISTOR	100K 5% 1/6W	
R 855	QRD161J-223	CARBON RESISTOR	22K 5% 1/6W	
R 856	QRD161J-222	CARBON RESISTOR	2.2 5% 1/6W	
R 857	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	
R 858	QRD161J-222	CARBON RESISTOR	2.2K 5% 1/6W	

9 Exploded View of Mechanism Component Parts and Parts List

● Mechanism Parts List

BLOCK NO. M1MM1111

Δ	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	1	VKL1273-00B	CHASSIS ASS'Y		1		
	2	VKH5078-001	COLLAR		1		
	3	WDL122525-4	SLIT WASHER	FOR CHASSIS	1		
	4	VKS5040-002	BRAKE F		1		
	5	VKS5041-002	BRAKE R		1		
	6	VKW3001-220	COMP.SPRING	FOR BRAKE F/R	2		
	7	VKL6324-001	T.U.LEVER(FWD)		1		
	8	VKL6325-001	T.U.LEVER(REV)		1		
	9	VKL6326-00B	LOCK ARM ASS'Y		1		
	10	VKW3002-243	TENSION SPRING	LOCK ARM-CHASSI	1		
	11	VKL6327-001	ACTUATOR PLATE		1		
	12	VKS5042-001	ACTUATOR RACK		1		
	13	SPSK2020M	MINI SCREW	FOR ACT.RACK	2		
	14	VKL2346-00C	HEAD BASE ASS'Y		1		
	15	VKH5078-002	COLLAR	FOR HEAD BASE	1		
	16	WFM163213	WASHER		1		
	17	VKH3000-136	COLLAR	FOR HEAD BASE	1		
	18	WDL122525-4	SLIT WASHER	FOR HEAD BASE	1		
	19	VKW3002-230	TENSION SPRING	H.BASE-CHASSIS	1		
	20	VKL3942-00A	H.M.BASE ASS'Y		1		
	21	VKL2349-00A	DISK BASE ASS'Y		1		
	22	VKL6330-00A	TAKE-UP BASE		1		
	23	WDL316025-4	WASHER		1		
	24	VKR4487-00A	DRIVE CL.ASS'Y		1		
	25	WDL173525-0	SLIT WASHER	FOR DRIVE CL.	1		
	26	VKR4491-00A	REEL DISK ASS'Y		2		
	27	WDL123025-0	SLIT WASHER	FOR REEL DISK	2		
	28	VKB3000-115	BELT		1		
	29	VKS3346-001	BELT HANGER	FOR BELT	1		
	30	VKR4495-00B	TAKE-UP CLUTCH		1		
	31	WFM163025	WASHER	FOR T.U.CL.	1		
	32	VKL6332-00A	F/R BASE ASS'Y		1		
	33	WDL123025-0	WASHER		1		
	34	VKL3945-00A	A.GEAR BRACKET		1		
	35	VKS5044-001	CAM GEAR		1		
	36	WDL122525-6	SLIT WASHER	FOR A.GEAR(2)	1		
	37	VKZ3143-00C	MODE SWITCH		1		
	38	SPSK2020M	MINI SCREW	FOR MODE SWITCH	2		
	39	VKS5045-001	A.GEAR (3)		1		
	40	VKS3322-001	CAM GEAR		1		
	41	WDL122525-4	SLIT WASHER	FOR A.GEAR (3)	1		
	42	VKL6334-00A	DIR.L.BBRACKET		1		
	43	WDL122525-4	SLIT WASHER	FOR DIR.LEV.BKT	1		
	44	SPSK2020M	MINI SCREW	FOR DIR.LEV.BKT	1		
	45	VKL6336-00B	DIR.LEVER ASS'Y		1		
	46	WDL122525-4	WASHER		1		
	47	MDN-4RB7MYA-1	A.MOTOR		1		
	49	VKS5046-002	A.MOTOR BUSH		1		
	50	VKS5047-003	A.GEAR (1)		1		
	51	SPSK2025M	MINI SCREW	FOR A.MOTOR	2		
	52	YK30C-CB401	PLAYBACK HEAD		1		
	53	VKZ4291-004	SPECIAL SCREW	FOR PB HEAD	2		
	54	VKW4733-002	WIRE COVER		1		
	55	VYSA1R4-083	SPACER		1		



BLOCK NO. M2MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	1	VKL1340-001	CHASSIS		1		
	2	VMA3179-001	INSULATOR		1		
	3	VKM3514-001	MECHA BRACKET		1		
	4	VKM3515-001	TOP COVER		1		
	5	VKM3528-002	REAR BRACKET		1		
	6	VMP3209-001	DIN CORD ASS'Y	13PIN CORD	1		
	9	VMP3210-001	PIN CORD ASS'Y	LINE IN	1		
	10	VMP3207-001	PIN COD ASS'Y	LINE OUT/REMOTE	1		
	11	VMP0029-009	ANTENNA CORD		1		
	12	VKL7073-001	PCB HOLDER	DOLBY BOARD	1		
	13	VKS3476-004	TUNER HOLDER	TUNER BOARD	1		
	14	VKZ4131-010	SPECIAL SCREW	MAIN BOARD	2		
	15	SDST2605Z	SCREW	MAIM BOARD	1		
	16	SDST2605Z	SCREW	MECHA. BRACKET	2		
	17	SDSP2606Z	SCREW	TOP COVER	2		
	18	SDST2605Z	SCREW	REAR BRACKET	2		
	19	SDST2605Z	SCREW	PCB HOLDER D	1		
	20	SDST2605Z	SCREW	S.PLATE	1		
	21	SSST2605Z	SCREW	PCB HOLDER T	1		
	22	LPSP3006Z	SCREW	SPIN BONNECTOR	1		
	23	SDST2605Z	SCREW	ANT CORD	1		
	24	SDST2605M	SCREW	FRONT CHASSIS	2		
	25	VJC2426-002	FRONT CHASSIS		1		
	26	VXP5058-001	RESET KNOB		1		
	27	SDSF2006Z	SCREW	RESET SWITCH	1		
	28	VKL7170-002	SWITCH BRACKET		1		
	29	VSH1142-001	SWITCH		1		
	30	VMA4519-001	EARTH PLATE(S)		1		
	31	LPSP2004Z	SCREW	E.PLATE + SW.BK	1		
	32	SPSK2060Z	MINI SCREW	SW + SW.BKT	1		
	33	SDSF2006Z	SCREW		2		
	34	SDSP2604Z	SCREW	SW BKT + LED PW	1		
	36	VKL2599-002	PANEL HOLDER		1		
	37	VKL7067-002	HOOK		1		
	39	VKH5596-001	COLLAR	HOOK PIN	1		
	40	WDL163225-0	SLIT WASHER		1		
	41	VKZ4586-002	MINI SCREW	HOOK	1		
	42	ZCKSCG10-COVER	CONNECTOR COVER		1		
	43	ZCKSCG10-CONN	CONNECTOR ASS'Y		1		
	46	VKL7061-00C	PANEL BRACKET		1		
	47	VKW4957-003	HOLDER SPRING		1		
	48	SDSF2010M	SCREW	PNL BKT ASS'Y(L)	1		
	49	SDSF2006M	SCREW	PNL BKT ASS'Y	1		
	50	VKL7063-00B	PANEL BRACKET		1		
	51	VKS5353-002	HOLDER GEAR		1		
	52	SPSL2040M	MINI SCREW	H.GEAR+HOLDER	1		
	53	SDSF2006M	SCREW	PNL BKT+F.CHASS	2		
	54	VKL7171-001	DAMPER BRACKET		1		
	55	VJY4035-00B	DAMPER ASS'Y		1		
	56	SDSP2004Z	SCREW		2		
	57	SDSF2006Z	SCREW	D.BKT+F.CHASSIS	2		
	58	VKL7148-002	SOLENOID BRACKE		1		
	59	VMA4518-002	EARTH PLATE(L)		1		
	60	LPSP2004Z	SCREW	EARTH PLATE	1		
	61	VGP2201-002	DC SOLENOID		1		

BLOCK NO. M2MM

A	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
	62	VKZ4586-002	MINI SCREW	SOLENOID	2		
	63	VKL7150-00B	LOCK LEVER ASSY		1		
	64	VKH5500-003	COLLOR	LOCK LEVER	1		
	65	VKW3001-290	COMP. SPRING	SOLENOID	1		
	66	LPSP2608Z	SCREW	LOCK LEVER	1		
	70	SPSF2006Z	SCREW	SOLENOID BRACKE	2		
	71	VJG1007-015	FRONT PANEL		1	B,E,GI	
		VJG1007-014	FRONT PANEL		1	G,GE	
	72	VYSH101-016	SPACER	AUX JACK	1		
	74	VYTT589-001	SHEET		1		
	75	VJD5355-002	FILTER	REMOTE	1		
	76	VJK3551-001	FINDER		1		
	80	VXP5057-001	RESET BUTTON		1		
	81	VKW3001-289	COMP.SPRING	RESET BUTTON	1		
	82	VXP5050-00C	BUTTON ASS'Y(L)		1		
	83	VXP5053-00B	BUTTON ASS'Y(R)		1		
	84	VJK3555-001	BUTTON LENS(L)		1		
	85	VJK3556-001	BUTTON LENS(R)		1		
	86	VYTT590-001	SEAL	BUTTON LANS	2		
	87	VYSH104-043	SPACER		2		
	88	SPSN1745N	MINI SCREW	B.LENS(L)	2		
	89	SPSN1745N	MINI SCREW	B.LENS(R)	2		
	90	VXP5054-007	PRESET BUTTON	PRESET 1	1		
	91	VXP5054-008	PRESET BUTTON	PRESET 2	1		
	92	VXP5054-009	PRESET BUTTON	PRESET 3	1		
	93	VXP5054-010	PRESET BUTTON	PRESET 4	1		
	94	VXP5054-011	PRESET BUTTON	PRESET 5	1		
	95	VXP5054-012	PRESET BUTTON	PRESET 6	1		
	96	VXP5055-001	POWER BUTTON		1		
	97	VXP5055-002	PUSH BUTTON	FUNCTION	1		
	98	VXP5055-003	PUSH BUTTON	SELECT	1		
	99	VXP5055-004	PUSH BUTTON	WOOFER	1		
	100	VXP5055-005	PUSH BUTTON	CLOCK	1		
	101	VXP5055-006	PUSH BUTTON	EJECT	1		
	102	VXP5056-001	PUSH BUTTON		3		
	104	VJK3571-002	LIGHT LENS(U)	PRESET,POWER	1		
	105	VJK3572-001	LIGHT LENS(L)		1		
	106	VYSH102-070	SPACER	B.LENS(U)	1		
	107	VYSH102-069	SPACER	B.LENS(L)	1		
	108	VYTH495-001	B.CUSHION(P)	POWER	1		
	109	SPSN1745N	MINI SCREW	B.LENS(U)	2		
	110	SPSN1745N	MINI SCREW	B.LENS(L)	2		
	111	VJG1008-002	REAR COVER		1		
	112	SPSN1780N	MINI SCREW	FRONT+REAR	4		
	113	VKS3529-003	LOCK CAM(L)		1		
	114	VKW4956-002	LOCK SPRING		1		
	115	VKS3530-003	LOCK CAM(R)		1		
	116	VKW4956-002	LOCK SPRING		1		
	117	VKL7096-001	TAP PLATE		1		
	119	VYSS1R4-035	SPACER		1		
	120	VYN3311-001SA	NAME PLATE		1	B,E	
		VYN3311-003SA	NAME PLATE		1	GI	
		VYN3311-020SA	NAME PLATE		1	G,GE	
	121	VND4163-004	CAUTION LABEL		1		

■ Mechanism




Fig. 9-1

BLOCK NO.

M	1	M	M			
---	---	---	---	--	--	--

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
56	VKL6338-001	DIRECTION PLATE		1		
57	VKW4711-002	P.R.SPRING	FOR DIR.PLATE	1		
58	SPSK2025M	MINI SCREW	FOR H.M.BASE	2		
59	VKW4712-001	RETURN SPRING	FOR P.R.ASS'Y(F	1		
60	VKP4190-00C	P.R.ASS'Y (F)		1		
61	REE1500X	E.RING	FOR P.R.ASS'Y(F	1		
62	VKW4713-001	RETURN SPRING	FOR P.R.ASS'Y(R	1		
63	VKP4192-00C	P.R.ASS'Y (R)		1		
64	REE1500X	E.RING	FOR P.R.ASS'Y(R	1		
65	VGP0706-002	DC SOLENOID		1		
66	SPSH2055M	MINI SCREW	FOR SOLENOID	1		
67	WDL163525-4	SLIT WASHER	FOR FLAPPER	1		
68	MCI-5D3LA	CAPSTAN MOTOR		1		
69	VKR4499-001	MOTOR PULLEY		1		
70	VKS5115-001	MOTOR COLLAR		2		
71	VKZ4483-004	MOTOR SPACER		1		
72	DPSP2005Z	SCREW	FOR CAPSTAN MOT	2		
74	SPSK2025M	MINI SCREW	FOR REEL UNIT	1		
75	WFM163013	WASHER		1		
76	VKR4500-001	CENTER PULLEY		1		
77	WDL122525-4	SLIT WASHER	FOR C.PULLEY	1		
78	VKF4182-00B	F.W.ASS'Y		2		
79	WFM197025	WASHER	FOR F.W.ASS'Y	2		
80	VKB3000-114	BELT		1		
81	VKS5048-002	THRUST HOLDER		2		
82	VKL3947-001	FW BRACKET		1		
83	SPSK2025M	MINI SCREW	FOR FW BRACKET	1		
84	VKZ4434-001	WASHER	FOR OIL CUT	2		
85	VKW4770-001	T.U.SPRING	FOR T.U.BASE-LE	2		
86	SPSK2025M	MINI SCREW	FOR A.GEAR UNIT	1		
87	SPSK2025M	MINI SCREW	FOR HOLDER BASE	3		
88	REE1500X	E.RING	FOR HOLDER BASE	1		
89	SPSK2025M	MINI SCREW	FOR AUTO P.C.BO	1		
90	DPSP2005Z	SCREW	FOR HEAD P.C.BO	1		
91	SPSK2025M	MINI SCREW	FOR SWITCH P.C.	1		
92	VKL6342-001	P.C.B.BRACKET		2		
93	SDST2604Z	SCREW		2		
94	VKL1276-00B	HOLD BASE ASS'Y		1		
95	VKL2355-002	CASSETTE HOLDER		1		
96	VYSA1R3-030	SPACER		1		
97	VKL2351-00A	LIFTER ASS'Y		1		
98	VKH3001-078	FLANGE COLLAR	FOR LIFTER	1		
99	SPSJ1730M	MINI SCREW	FOR LIFTER	1		
100	VKL2353-00B	LIE SLID ASS'Y		1		
101	VKS5049-001	LOADING RACK		1		
102	SPSK2025M	MINI SCREW	FOR LOADING RAC	2		
103	VKH3000-132	COLLAR	FOR R.SLIDER	1		
104	REE1500	E.RING	FOR R.SLIDER	1		
105	VKS3335-00B	CASSETTE SLIDER		1		
106	VKH5077-001	C.SLIDER COLLAR		1		
107	VKL3948-00A	LOADING LEVER		1		
108	REE1500	"E" WASHER		1		
109	VKL3950-00B	EJECT LEVER		1		
110	VKL6341-002	LOCK ARM		1		

BLOCK NO.

M	1	M	M				
---	---	---	---	--	--	--	--

[illegible]

BLOCK NO. M2MM

REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
123	VKZ4521-004	SCREW		1		
124	VND4411-001	CAUTION LABEL		1		
125	VYTA496-001T	DIN CAP		1		
126	VYTA500-001	PIN CAP		8		
127	LPSP2606Z	SCREW	MECHA+CHASSIS	2		
128	SPST2605Z	SCREW	MECHA+MECHA BKT	2		
129	VYSA1R4-056	SPACER		2		
130	VKS5396-001	LED HOLDER		1		
131	VMZ0102-001	INTER CONNECTOR		1		
132	VYTT581-001	SCREEN		1		
133	VJK3554-001	LCD LENS		1		
134	VYTT590-002	SEAL		1		
135	VKM3570-001	LCD CASE		1		
136	VYSS1R4-034	SPACER		1		
137	VYTR442-001	LAMP HOLDER		4		
138	VYTS503-004	INSULATOR		1		
139	VYTS504-001	INSULATOR(P)		1		
140	VYSS1R5-032	SPACER	R.BKT-MAIN PB	1		
141	VYSH108-018	SPACER	FOR DOLBY BOARD	1		
144	VMA4397-002	SHIELD PLATE	FOR TUNER PACK	1		
150	ZCKSCG10E-NPA	NOSE PIECE ASSY		1	B,E,GI	
	ZCKSCG10GR2-NPA	NOSE PIECE ASSY	FROM #1001-	1	G,GE	
151	ZCKSCG10-REAR	REAR PANEL ASSY		1		

11 Packing Illustration and Parts List




Fig. 11-1

● Packing Parts List

BLOCK NO. M3MM

△	REF.	PARTS NO.	PARTS NAME	REMARKS	QTY	SUFFIX	CLR
A	1	VNN3311-451	INSTRUCTIONS	HOL/SWD/SPAIN	1	E	
		VNN3311-471	INSTRUCTIONS		1	GI	
		VNN3311-481	INSTRUCTIONS	FINLAND	1	E	
		VNN3311-212	INSTRUCTIONS		1		
A	2	BT-20066A	WARRANTY CARD		1	B	
		BT20060	WARRANTY CARD		1	B	
		BT-20114	WARRANTY CARD		1	G	
A	3	PU36158	FTZ INF.SHEET		1	G	
A	4	E43486-340B	SAFETY SHEET		1	B	
A	5	VKL5460-001	STAY		1		
A	6	SSSP5006Z	SCREW		4		
A	7	VKZ4027-002	PLUG NUT		1		
A	8	VKH4871-001	MOUNT BOLT		1		
A	9	VKZ4328-001	LOCK NUT		1		
A	10	WNS5000Z	WASHER		1		
A	11	VKY4462-004	SIDE SPRING		2		
A	12	SSSP4006Z	SCREW		4		
A	13	VJH4089-001	HANDLE HOLDER		2		
A	14	SPSL2040M	MINI SCREW		1		
A	15	VND4410-001	SHEET		1		
A	16	VKL3732-015	MOUNTING SLEEVE		1		
A	17	JV-0062-11	REMOCON UNIT	RM-RK10	1		
A	18	UM-4NJ-2P	BATTERY		2		
A	19	VMC0014-090	5P CORD ASS'Y		1		
A	20	VJD3881-001	TRIM PLATE		1		
A	21	VND4418-001	DYNAS STICKER		1		
A	22	VND3050-001	IDENTITY CARD		1		
A	KIT	KSRX4307-SCREW1	SCREW KIT	A6-A13 KIT	1		
B	KIT	KSRX4307-SCREW2	SCREW KIT	A14-A15 KIT	1		
P	1	VPC3311-001	CARTON		1		
P	3	VPE3005-066	POLY BAG	FOR SET	1		
P	4	VPK4231-014	SPACER		1		
P	5	QPGA008-01205	POLY BAG		1		
P	6	QPGA008-01205	POLY BAG	FOR SCREW SET	1		
P	7	QPGBO17-02404	POLY BAG		1		
P	8	VND3046-003	SERIAL TICKET		1	E	
		VND3046-004	SERIAL TICKET		1	B	
		VND3046-001	SERIAL TICKET		1	GI,GE	
		VND3046-005	SERIAL TICKET		1	G	
P	9	VJB3034-001	HARD CASE		1		
P	11	QPGA010-02505	POLY.BAG		1		
P	12	QO4141H	WIRE CLAMP		1		
P	13	VND3071-042	EAN CODE LABEL		1		
P	2-1	VPH1552-002	CUSHION(L)		1		
P	2-2	VPH1553-002	CUSHION(R)		1		

JVC

VICTOR COMPANY OF JAPAN, LIMITED
PERSONAL AUDIO PRODUCTS DIVISION 10-1, 1-chome, Ohwatari-machi, Maebashi-city, Japan